

# SEFRAM 9862

## Hot Wire Anemometer



## Instruction Manual

32, rue Edouard Martel  
BP55  
F42009 – Saint Étienne Cedex 2  
E-mail: [sales@sefram.fr](mailto:sales@sefram.fr)

Tel : 04 77 59 01 01  
Fax : 04 77 57 23 23  
Web : [www.sefram.fr](http://www.sefram.fr)

# CONTENTS

TITLE	PAGE
<b>1. General Description</b> .....	1
<b>2. Safety Information</b> .....	1
<b>3. Application</b> .....	1
<b>4. Features</b> .....	1
<b>5. Specifications</b> .....	2
<b>6. Symbol Definition and Button Location</b> .....	3
<b>7. Button Instructions</b> .....	6
7.1 Power ON/OFF/ Backlight button.....	6
7.2 Data-Hold button.....	6
7.3 MAX/MIN/AVG button.....	6
7.4 Flow button.....	6
7.5 Unit button.....	7
7.6 °C /°F Button.....	7
<b>8. Operating Instructions</b> .....	7
8.1 Setup Options.....	7
8.2 Menu Item.....	7
8.3 Menu Description.....	9
8.3.1 Set Duct Area.....	9
8.3.2 Set Absolute pressure.....	9
8.3.3 Set auto power off time.....	9
<b>9. Measuring Procedure</b> .....	10
9.1 Extending the Probe.....	10
9.2 Using the Telescoping Probe.....	10
<b>10. Power Preparation</b> .....	10
10.1 Battery Replacement.....	10
10.2 AC Adapter Connection.....	11
<b>11. Maintenance</b> .....	11

## 1. GENERAL DESCRIPTION

Thank you for choosing our Hot Wire Anemometer. To ensure the safety and the best performance of this instrument, we recommend you to read and follow the manual carefully before operation.

## 2. SAFETY INFORMATION

Read the following safety information carefully before attempting to operate or service the meter. Use the meter only as specified in this manual; otherwise, the protection provided by the meter may be impaired.

### \*\* DANGER \*\*

The meter is not designed for use in gas mixtures other than air. **DO NOT** use the unit with corrosive or other dangerous or explosive gas mixtures.


### ENVIRONMENT CONDITIONS

- Altitude up to 2000 meters
- Relatively humidity: 90% max
- Operation ambient temperature: 0°C to 50°C

### MAINTENANCE & CLEARING

- Repairs or servicing not covered in this manual should only be performed by qualified personnel.
- Periodically wipe the case with a dry cloth. Do not use abrasives or solvents on this instrument.

### SAFETY SYMBOLS

 Comply with EMC

When servicing, use only specified replacement parts.

## 3. APPLICATION

- Measuring volumetric flow rates or flow velocities in ducts
- Measuring the temperature and humidity of flows
- HVAC system performance

## 4. FEATURES

- Fast response.
- Telescoping hot wire probe.
- Air flow measure: CMM, CFM.
- Air velocity measurement:  
m/s, km/hr, ft/min, MPH, Knots & build in temperature °C / °F, humidity RH.
- Large LCD display with backlight.
- Min/Max/Avg & 2/3Vmax function.
- Data Hold function.
- With USB interface supply power.


- Battery Life indicator.
  
- Adjustable auto power off timer.
- Air velocity compensation in atmospheric pressure.
- Tilt Stand.



## 5. SPECIFICATIONS

<b>Velocity Probe Range:</b>	0 to 30 m/s(0 to 6000 ft/min) 0 to 999900 m <sup>3</sup> /min(ft <sup>3</sup> /min) -20 °C ~60 °C (-4 °F ~140 °C) 0~100%RH
<b>Resolution:</b>	0.01 m/s(1 ft/min) 0.001 m <sup>3</sup> /min(ft <sup>3</sup> /min) 0.1 °C /°F 0.1%RH
<b>Accuracy:</b>	(at 23 °C ± 5 °C <80%RH) ±3% of reading ± 1%FS (0 to 20 m/s) ±5% of reading ± 1%FS (20 to 30 m/s) ±0.8 °C (±1.5 °F) ±3.5%RH at (20% ~ 80%RH) ±5%RH at (0% ~ 100%RH)
<b>Warm Up Time:</b>	5 seconds
<b>Sample Rate</b>	2 time per second
<b>Battery:</b>	9V Alkaline battery
<b>USB Power Adapter:</b>	DC 5V 0.5A
<b>Battery Lifetime</b>	Approx. 10 hours (alkaline battery)
<b>Operation Temperature</b>	
<b>Meter / Probe :</b>	0°C to 50°C (32°F to 122°F) / -20°C to 60°C (-4°F to 140°F)
<b>Operation Humidity:</b>	10 to 90%RH (no condensing)
<b>Storage Temperature:</b>	-20°C to 60°C (-4°F to 140°F)
<b>Storage Humidity:</b>	10 to 75%RH
<b>Dimensions:</b>	Meter: 185mm(L) × 65mm(W) × 36mm(H) / 7.28 inches(L) × 2.56 inches(W) × 1.41 inches(H) Wire length: 185 cm Probe length: 87 cm Probe diameter of tip: 9.0 mm Probe diameter of base:16.0 mm
<b>Weight:</b>	Approx.412 g(included battery and probe)


Standard Accessories : Instruction manual, battery 9V Alkaline x 1 pcs, carrying case.

## 6. SYMBOL DEFINITION & BUTTON LOCATION



	: Battery condition indicator
<b>VEL</b>	: Air velocity indicator
<b>MIN</b>	: Air velocity Minimum indicator
<b>MAX</b>	: Air velocity Maximum indicator
<b>AVG</b>	: Air velocity Average indicator
	: Auto Power Off enabled indicator
<b>0000</b>	: Air velocity reading
<b>knots ft/min km/hr mile/hr m/s Bft</b>	: Air velocity measurement units
<b>FLOW</b>	: Air flow indicator
<b>MAX</b>	: Air flow Maximum indicator
<b>2/3V MAX</b>	: Air flow 2/3V Maximum indication
<b>AVG</b>	: Air flow Average indicator
<b>0000</b>	: Air flow reading

<b>X10</b>	: Multiply reading by ten
<b>X100</b>	: Multiply reading by one hundred
<b>X1000</b>	: Multiply reading by one thousand
<b>m<sup>3</sup>/min ft<sup>3</sup>/min/s</b>	: Air flow measurement units
<b>cm<sup>2</sup> ft<sup>2</sup> in<sup>2</sup></b>	: Area setting units
<b>AREA</b>	: Duct Area indication
<b>○</b>	: Round Duct diameter dimension indication
<b>□ XY</b>	: Rectangle Duct X and Y dimension indication
<b>hpa inHg</b>	: Pressure indication
<b>-188.8</b>	: Temperature reading
<b>°C °F</b>	: Temperature measurement units
<b>188.8</b>	: Relative Humidity reading
<b>% RH</b>	: Relative Humidity measurement units
<b>HOLD</b>	: Data hold indication







- ,1 Sensor Probe (Measurement direction)
- ,3 Telescoping Probe
- ,5 Power ON/OFF and Back Light Button
- ,7 FLOW MAX 2/3VMAX AVG Button
- ,9 Unit Button
- ,11 Power Source Interface(micro USB type)
- ,13 Battery Compartment


- ,2 Protective Shutter
- ,4 Display Screen
- ,6 MAX MIN AVG Button
- ,8 DATA HOLD Button
- ,10 °C/°F Button
- ,12 Tilt Stand

## 7. BUTTON INSTRUCTIONS

### 7.1 Power ON/OFF/ Backlight Button:

Press the  button to turn on the meter and then press the  to turn on the LD backlight. Press  again to turn off backlight. This makes it easier to read in dark environment. The backlight will be automatically turned off after 30 seconds to save battery power. Press and hold  button for 3 seconds to turn off. There is a 5 second count down as the meter warms up.

### 7.2 Data-Hold Button :





Press  button to freeze the data shown on the LCD screen. Press it again to exit Data-Hold mode.

**Note:** When the unit is in the Data-Hold mode,  /  /  /  buttons are disabled.


### 7.3 MAX/MIN/AVG Button:

Under this mode, the unit simultaneously monitors and stores the maximum, minimum and average value in the memory. The unit will keep updating/refreshing the data.

**To start:**

- (1) Press  button. “ **MAX** ” symbol lights up on LCD, the reading shows the maximum data.
- (2) Press  button again to show minimum data; the “ **MIN** ” symbol lights up on LCD.
- (3) Press  button again to show average data; the “ **AVG** ” symbol lights up on LCD.
- (4) Press  button again, the “ **MAX, MIN and AVG** ” symbol blinks together, the readings shows real time data.

**To exit MAX/MIN/AVG mode:**




Press and hold  button for 2 seconds to exit MAX/MIN/AVG mode.

### 7.4 FLOW Button :


**AIR FLOW = (AIR VELOCITY) x (AREA)**

Under this mode, the unit simultaneously monitors and stores the maximum, 2/3V maximum and average value in the Air flow. The unit will keep updating/refreshing the data.


**To start:**

- (1) Press  button. “ **MAX** ” symbol lights up on LCD, the reading shows the maximum data.
- (2) Press  button again to show two-third Velocity maximum data; the “ **2/3V MAX** ” symbol lights up on LCD.
- (3) Press  button again to show average data; the “ **AVG** ” symbol lights up on LCD.




- (4) Press  button again, the “ **MAX, 2/3V MAX** and **AVG** ” symbol blinks together, the readings shows real time data.


**To exit MAX/2/3V MAX/AVG mode:**

Press and hold  button for 2 seconds to exit MAX/2/3VMAX/AVG mode.

**7.5 Unit Button:**






Press  to select the desired unit of air velocity.

**7.6 °C/°F Button:**

Press  to select the desired unit of temperature.

## 8. OPERATING INSTRUCTIONS

**8.1 Setup Options:**

- (1) Power off the meter and then press the  and  button for 3 seconds to enter setup mode. Press  to exit anytime.
- (2) Press the  button to enter the setting option.
- (3) Press the  button to save changes and move to next setting option.

**8.2 Menu Item:**



Fig.1 Setup mode.



Fig.2 Set Area.



(3) Fig.3 Set Round Duct diameter dimension.



(4) Fig.4 Set Rectangle Duct X dimension.



(5) Fig.5 Set Rectangle Duct Y dimension.



(6) Fig.6 Set absolute pressure.



(7) Fig.7 Set auto power off time.

## 8.3 Menu Description:

### 8.3.1 Set Duct Area

There are 3 types : Duct Area (AREA), Round Duct (○), Rectangle Duct (□),

(1) Press the **FLOW** button to select the type and then press the **HOLD** button to confirm your choice.

(2) If duct area is chosen, the “ **AREA** ” symbol will displayed. (Fig.2)

Press the **Unit** or **°C/°F** button to set the size from 1 cm<sup>2</sup> to 40 m<sup>2</sup> (0.001 to 430.0 ft<sup>2</sup>).

Press the **HOLD** button to store the value.

If round duct is chosen, the (○) symbol will displayed. (Fig.3)

Press the **Unit** or **°C/°F** button to set the size (diameter) from 1 to 635 cm (0.4 to 250 in).

Press the **HOLD** button to store the value.

If rectangle duct is chosen, the “ □ **X** ” symbol will displayed. (Fig.4)

Press the **Unit** or **°C/°F** button to set the size of the duct ,then press the **HOLD** button to store the value and advance to the next dimension, the “ □ **Y** ” symbol will displayed.

Press the **Unit** or **°C/°F** button to set the size of the duct.

Press the **HOLD** button to store the value.

### 8.3.2 Set Absolute pressure

Press the **Unit** or **°C/°F** button to set absolute pressure from 100 to 2000 HPA (59 to 2.95 inHg) and then press the **HOLD** button to store the value.

### 8.3.3 Set auto power off time:

(1) Press the **Unit** or **°C/°F** button to select auto power off option 10, 30 minutes, 1, 2, 4, 8 hours, or off. (see Fig.8 or Fig.9)



Fig.8



Fig.9

## 9. MEASURING PROCEDURE


### 9.1 Extending the Probe

Open the protective shutter and then extend the probe. Do not hold the cable while extending the probe.

### 9.2 Using the telescoping Probe


Put the probe in the right position and make sure that the sensor window is fully exposed and is facing upstream

\* If in the right direction, the user will see the white-arrow marking as following figure



## 10. POWER PREPARATION


### 10.1 Battery Replacement:

(1) When the battery voltage drops below proper operation range, the  symbol will blink on the LCD display and the battery needs to be replaced.

(2) Before replacing the battery, power off the meter.

Open the cover of the battery cabinet. Replace the old batteries with new 9V alkaline battery (Carbon-zinc batteries are not recommended).

(3) Close the battery cabinet cover.



## 10.2 AC Adapter Connection:

When the AC adapter is used, insert the plugs of the adapter into the USB connector on the side panel.

**Note:**

When the AC adapter is connected while battery is inserted, the unit will be powered from the adapter (the AC adapter has priority).

## 11. Maintenance

Clean the device and the window of the display with a clean, lint-free, antistatic and dry cleaning cloth.

**⚠ Do no use cleaning agents that contain carbon or benzenes, alcohol or anything similar to clean the product since these substances damage the surface of the measuring instrument. Moreover, these fumes are hazardous to health and explosive. Do not use tools with sharp edges, screwdrivers, metal brushes or anything similar to clean the device.**