Size:105 x145mm

GP PowerBank
MOBILE CHARGER

Instruction Manual
1C02A

COVER

P.1

1C02A

GP PowerBank
MOBILE CHARGER

Instruction Manual





Output 1 : for iPhone / Android phones / iPad
* USB power adaptor is not included in packaging.

Supports:

Smartphones, Tablet PCs, Mobile Phones, MP3 Players, Gaming Devices, Camcorders, Digital Cameras

Specifications

Input	5V DC 1A
Output	5V DC 1A
Dimension	30(L) x 22(W) x 70(H) mm
Weight (Power Pack only)	65g
Operating Temperature	0°C ~ 40°C
Battery Type	Li-ion battery 3.7V 2600mAh
Recharging Time	6 hours(approx.)^

^ The above recharging time may vary under different operating conditions. Longer charging time might be needed in the first charge.

LED indication

During recharging, the LED displayed on the front side of the PowerBank will light up.

Checking the battery status: (Table 1)

Battery Strength	LED Indicator	Remarks
Good	Flash for 4 times	No need for recharging
Good to average	Flash for 3 times	-
Average	Flash for 2 times	-
Weak	Flash for 1 time	Need to be recharged
No power	LED off	Need to be recharged immediately

GB

Product Features

- Pocket friendly PowerBank with built-in 2600mAh lithium-ion battery, perfect for smartphone .
- Convenient to recharge via USB power port from computer in use# or by USB power adaptor*
- Safety protection
  - Over charging / discharging protection
  - Overload protection
  - Short circuit protection
- LED indicator to show battery level

Read the instruction manual thoroughly before use. Keep the manual for future reference.

Operating Instructions:
Recharging the PowerBank

1. Plug the micro USB port of the provided USB charging cable into the input port of the PowerBank. Connect the other end of the cable to a computer# (Fig. 1) in use or USB power adaptor* (1A or up) (Fig.2) to AC power outlet. It is recommended to use the USB cable provided by GP for recharging.
2. The LED indicator will be on to show the charging status.
3. Disconnect the USB cable after recharging.

Charging Other Electronic Devices

1. Plug the provided USB charging cable into the USB output port of the fully recharged PowerBank. Connect the other end of the cable to the electronic device. Using the original USB cable provided by the electronic device is also accepted.(Fig. 3)
2. Charging starts in 3 seconds otherwise unplug and reconnect.
3. Refer to the electronic device to check the charging status if necessary.
4. Unplug after charging and the PowerBank will turn off automatically.

Caution

1. The LED light will be on and flash fast when the PowerBank is an abnormal condition. In this case, unplug the charging cable and for at least 1 minute, press the front button of the PowerBank and place it at room temperature for the return to normal operation.
2. It is normal that the casing gets warm during charging and the PowerBank will gradually cool down to room temperature after use or fully recharged.
3. Do not use the PowerBank at any application environment which is enclosed, extremely humid or hot, or close to an oven and open flame, or under direct sunlight to prevent overheating. GP does not accept any warranty or return for any damage to the battery or the internal components.
4. This appliance is no intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely. Young children should be supervised to ensure that they do not play with the appliance.
5. Do not wet, burn, modify, disassemble, open, drop, crush, puncture or ruin the PowerBank casing and the internal battery. GP does not accept any warranty or return for any damage to the battery or the internal components.
6. Do not throw or shake the PowerBank.
7. Keep away from the A/C main source and do not take power from sources other than from the USB port.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

P.2

P.3 P.4 P.5 P.6 P.7 P.8

P.11 P.12 P.13 P.15 P.17 P.19 P.21