



DAA-16, DAA-32

### DAA-16, DAA-32

#### Three-phase adapter 16 A or 32 A

- Three-phase current plug CEE 16 A or CEE 32 A
- Connections via five separate 4 mm sockets for L1, L2, L3, N and PE
- For quick connection of test devices to three-phase sockets when testing according to DIN VDE 0100

#### Ordering Information:

Description	Model	Article no.
DAA-16*	DAA-16	2743806
DAA-32*	DAA-32	2743850

\* with Schuko plug



### Three-phase adapter 1142

- For testing portable equipment with the plugs: 16 A CEE 3-pole, 16 A CEE 5-pole, and 32 A CEE 5-pole
- Measurement of protective earth resistance and insulation resistance
- Suitable for all test equipment with an earthed socket and test probe

#### Ordering Information:

Description	Model	Article no.
Three-phase adapter*	1142	3313394

\* with Schuko plug



1240/1241

### Three-phase adapter 1240/1241

- For testing portal devices with three-phase current plug 16 A CEE 5-pole (1240) or 32 A CEE 5-pole (1241)
- Measurement of protective earth resistance and insulation resistance
- Suitable for all test equipment with an earthed socket

#### Ordering Information:

Description	Model	Article no.
Three-phase adapter 16A*	1240	3313412
Three-phase adapter 32A*	1241	3313420

\* with Schuko plug