

UAT-600-EUR Series Underground Utilities Locator

Accurately and safely pinpoint underground utilities before you dig

Accidentally hitting an utility line during a project can lead to costly repairs and create hazardous public safety situations. Digging in the wrong place can also lead to unnecessary delays and costs for your project, and ultimately, your company. Avoid this disruption with the rugged and durable Beha-Amprobe UAT-600-EUR Series, designed to accurately pinpoint underground utilities and buried services.

Designed for electricians with a CAT IV 600 V rating, the locating kits come complete and ready for use with a Transmitter, Receiver, test lead kit, batteries and additional fuses, all in a mobile, protective duffle bag.

Features and Highlights

- **Multiple tracing modes** allow you to locate and trace energized and de-energized utilities in a variety of applications
- The intuitive Transmitter automatically chooses the correct locating function based on the connected accessory and includes selectable 8/33 kHz frequencies
- The Receiver's high-contrast display allows for clear viewing in full sunlight and features an automatic backlight for shaded and dark areas
- Rated CAT IV 600 V, ensuring safety when working with energized cables
- Semi-automatic gain control quickly detects tracing signal and allows precise adjustment of the receiver sensitivity
- Accurate depth measurement to 6 meters, detect and trace utilities buried up to 30 meters deep
- **Rugged, durable construction:** water and dust resistant to IP54 and drop proof to 1 m (3.28 ft)
- Use the Signal Clamp to induce a signal without making electrical contact

The UAT-620-EUR kit also includes a Signal Clamp for

in combination with the optional A-Frame accessory.

transmitting a signal when it is not possible to make electrical

ground fault locating is required, use the UAT-600-TE Transmitter

(UAT-620-EUR)

contact with the cable to be traced. For applications where

- **Ground fault locating** with the optional A-Frame accessory
- Comes as a complete kit, ready for use



Beha-Amprobe® Division of Fluke Corp. (USA) c/o Fluke Europe BV In den Engematten 14 79286 Glottertal, Germany Tel. +49 (0) 7684 - 8009-0 info@beha-amprobe.de beha-amprobe.de Science Park Eindhoven 5110 NL-5692 EC Son The Netherlands Tel. +31 (0) 40 267 51 00 beha-amprobe.com 52 Hurricane Way NR6 6 JB United Kingdom info@beha-amprobe.co.uk beha-amprobe.com electricity are listed by a 3rd party safety lab, either UL or CSA. This system assures that Beha-Amprobe products meet or exceed safety regulations and will

vears to come.

perform in a tough, professional environment for many



AF-600-EUR A-Frame **Ground Fault Locator**

Save time and money by pinpointing leakage points

Ground faults are a common problem with electrical cables. Find any fault with the AF-600-EUR A-Frame cable ground fault locator, specifically designed for use with the Beha-Amprobe UAT-600-EUR Series.

Set up the UAT-600-TE Transmitter to apply a fault find signal to the utility under test, the AF-600-EUR A-Frame receives the signal and locates the place of the fault. The AF-600 will pinpoint where a cable metal conductor (either a sheath or a metallic conductor of the wire) touches the ground and can also detect other conductors to ground faults such as pipeline coating defects.

Features and Highlights

- Identify any point of leakage around a cable
- Locate cable and wire ground faults, sheath faults or pipeline coating defects, where the utility is in direct contact with the ground
- Find the exact point where metal is touching the ground and power is leaking, ie, a shield is rusted or a rubber buffer is broken, creating noise on a cable
- Advanced technology and digital signal processing makes pinpointing process fast, accurate and clear:
 - Compass guidance with numeric fault field strength indicates the direction of the fault
 - Distance sensitive left and right arrows guides the user to precisely follow the path of the buried utility
 - Automatic gain control quickly detects tracing signal and precisely adjusts the A-Frame sensitivity
 - Adjustable volume controls



The AF-600-EUR comes complete with batteries and a carrying case

Beha-Amprobe® Division of Fluke Corp. (USA) c/o Fluke Europe BV

In den Engematten 14 79286 Glottertal, Germany Tel. +49 (0) 7684 - 8009-0 info@beha-amprobe.de beha-amprobe.de

Science Park Eindhoven 5110 NL-5692 EC Son The Netherlands Tel. +31 (0) 40 267 51 00 beha-amprobe.com

52 Hurricane Way NR6 6 JB United Kingdom info@beha-amprobe.co.uk beha-amprobe.com

Clearly view the LCD display in bright sunlight

Pinpoint fault location by using the AF-600-EUR with the UAT-600-TE Transmitter



Specifications

	AF-600-EUR A-Frame	
Tracing mode (de-energized)	8 kHz	
Locating mode	Ground fault locating	
Sensitivity (typical)	Cable locate mode at 1 meter depth: 10 uA Fault locate mode: up to 2 M Ω fault	
Display backlight	Automatic	
Audio indication	Speaker indicates left/right by pulsed/continuous tone	
Compatible transmitter	UAT-600-TE Transmitter	
Display	1.28 in, 128 x 128 BW outdoor LCD display with auto backlight	
Update rate	Instantaneous	
Operating temperature and humidity	-20 °C to 50 °C (-4 °F to 122 °F), ≤90% RH	
Storage temperature and humidity	-40 °C to 60 °C (-40 °F to 140 °F), ≤90% RH	
Operating altitude	< 2000 m (< 6561 ft)	
Pollution degree	2	
Water and dust resistance	IP54	
Drop proof	1 m (3.28 ft)	
Power supply	(6) 1.5 V AA alkaline batteries	
Auto power off	15 minutes idle	
Battery life	Approx. 60 hours at 21 °C (70 °F) (Typical)	
Certifications	. B ., CE 💩 🕼	
Safety compliance	IEC 61010-1, CSA/UL 61010-1	
Size (H x W x L)	Approx. 355 x 230 x 120 mm (14 x 9 x 4.7 in)	
Weight	Approx. 1.9 kg (4.2 lb) (batteries installed)	

AF-600-EUR A-Frame includes: A-Frame Receiver, (6) 1.5 V AA (IEC LR6) Batteries, Carrying Case, User Manual





SC-600-EUR Signal Clamp (included in the UAT-620-EUR Kit only)

The Signal Clamp accessory provides an efficient and safe method of applying a locate signal to a cable, enabling the Transmitter to induce a signal through the insulation into the wires or pipes. The clamp works on low impedance closed circuits only.

	SC-600-EUR Signal Clamp	
Measurement category	CAT IV 600 V	
Operating voltage/current	0 to 600 V, 100 A max.	
Operating frequency/ tracing modes	33 kHz and 8 kHz	
Signal voltage output (nominal)	"23 V rms at 8 kHz 30 V rms at 33 kHz"	
Operating temperature and humidity	-20 °C to 50 °C (-4 °F to 122 °F), ≤90% RH	
Storage temperature and humidity	-40 °C to 60 °C (-40 °F to 140 °F), ≤90% RH	
Operating altitude	< 2000 m (< 6561 ft)	
Pollution degree	2	
Water and dust resistance	IP54	
Drop proof	1 m (3.28 ft)	
Certifications	. ®∴ C € ∠ ⊗ 1%	
Safety compliance	"IEC 61010-1, IEC 61010-2-033 CSA/UL 61010-1, CSA/UL 61010-2-033"	
Size (H x W x L)	Approx. 295 x 180 x 37 mm (11.6 x 7.1 x 1.4 in)	
Weight	Approx. 0.85 kg (1.9 lb)	

TL-UAT-600 Test Leads Kit



Test Leads Kit (included in the UAT-610-EUR and UAT-620-EUR Kits)

	TL-UAT-600 Test Leads Kit
Measurement category	CAT IV 600 V
Operating voltage and current	Test leads: 600 V, 10 A max. Clips : 600 V, 10 A max.
Leads length	3.5 m (11.5 ft)
Compatible transmitter	UAT-600-TE Transmitter
Operating temperature and humidity	-20 °C to 50 °C (-4 °F to 122 °F), ≤90% RH
Storage temperature and humidity	-40 °C to 60 °C (-40 °F to 140 °F), ≤90% RH
Operating altitude	< 2000 m (< 6561 ft)
Pollution degree	2
Water and dust resistance	IP54
Drop proof	1 m (3.28 ft)
Certifications	. @ :, CE 💩 🎉
Safety compliance	IEC 61010-031 CSA/UL 61010-031
Size (H x W x L)	Approx. 230 x 90 x 80 mm (9 x 3.5 x 3.1 in)
Weight	Approx. 0.5 kg (1.1 lb)

TL-UAT-600 Test Leads Kit includes: Black test lead with detachable black alligator clip, Red test lead with permanently attached red alligator clip, Ground stake



Beha-Amprobe® Division of Fluke Corp. (USA) c/o Fluke Europe BV

In den Engematten 14 79286 Glottertal, Germany Tel. +49 (0) 7684 - 8009-0 info@beha-amprobe.de beha-amprobe.de

Science Park Eindhoven 5110 NL-5692 EC Son The Netherlands Tel. +31 (0) 40 267 51 00 beha-amprobe.com



©2018 Beha-Amprobe® 6011655A-en





Trace an individual utility by connecting the transmitter directly with the test leads

Main applications

- Locate energized 50/60 Hz cables carrying current
- Identify the location of all metallic utilities: pipes*, energized and de-energized cables
- Trace individual pipes* or cables (energized or de-energized)
 *Tracing of non-metallic pipes and conduits is possible after inserting metal fish tape or cable

Two passive modes using only the UAT-600-RE Receiver

- Passive power mode (50/60 Hz) tracing energized lines conducting current (no Transmitter necessary)
- Passive radio mode (RF) using surrounding radio waves to trace underground utilities (no Transmitter necessary)



The Transmitter will automatically change modes based on which accessory is plugged in

Three active modes using the UAT-600-TE Transmitter

- Induction the Transmitter will automatically start to radiate a signal around it using an internal antenna, used for tracing individual cables where there is no access to the line to connect test leads or a clamp
- Direct connection with test leads - the most reliable method to trace individual cable or a pipe
- Clamp (Included in the UAT-620-EUR kit, optional for the UAT-610-EUR kit)
 provides an efficient and safe method of applying a locate signal to a cable, where it is not possible/safe to gain access to a cable for making an electrical contact



The Receiver's high contrast LED screen is easy to read in full sunlight

Special applications

- 2 frequency options: 8 kHz and 33 kHz
- Locate non-metallic pipes and sewer lines
- Take depth and current measurements
- Measure voltage, resistance and output current
- Advanced locating with two people
- Locate ground faults with the AF-600-EUR A-Frame accessory

Customers who use Beha-Amprobe Underground Locators

- Commercial and Residential Construction Contractors
- Water, Gas and Electric Installation and Repair Crews
- Pipe Laying Contractors
- Cable TV & Telecommunication
 Companies
- Electricians & General Contractors

Features

	UAT-600-RE Receiver	UAT-600-TE Transmitter	SC-600-EUR Signal Clamp
Measurement category	CAT IV 600 V	CAT IV 600 V	CAT IV 600 V
Operating voltage/current	0 to 6	500 V	0 to 600 V, 100 A max.
Operating frequency/tracing modes	Active tracing: 33 kHz and 8 kHz Passive tracing: 50/60 Hz and Radio	Energized circuit Induction mode: 33 kHz Direct connection modes: 8 kHz and 33 kHz Clamp mode: 8 kHz and 33 kHz De-Energized circuit Induction mode: 33 kHz Direct connection modes: 8 kHz, 33 kHz, A-Lo/A-Hi A-Frame: 8 kHz Clamp mode: 8 kHz and 33 kHz	33 kHz and 8 kHz
ocating modes	Peak and Null	-	-
Depth measurement and accuracy	Up to 20 ft 4 in to 10 ft: ± 3 % 10 ft to 20 ft: ± 5 %	-	_
Display backlight	Automatic	Yes	-
Audio indication	Increasing closer to the signal	Fast beeps showing the better signal is applied	_

Division of Fluke Corp. (USA) c/o Fluke Europe BV

In den Engematten 14 79286 Glottertal, Germany Tel. +49 (0) 7684 - 8009-0 info@beha-amprobe.de beha-amprobe.de Science Park Eindhoven 5110 NL-5692 EC Son The Netherlands Tel. +31 (0) 40 267 51 00 beha-amprobe.com





Specifications

specifications			\smile
	UAT-600-RE Receiver	UAT-600-TE Transmitter	SC-600-EUR Signal Clamp
Transmitting mode power output	_	Max. 3 watts	-
Output voltage	-	Max. 50 V rms	-
Output current	-	Max. 250 mA rms, constant current in 5 steps	-
Signal voltage output (nominal)	-	-	23 V rms at 8 kHz 30 V rms at 33 kHz
Mains voltage measurement	-	0 V to 600 V, 50 Hz to 60 Hz Resolution: 1 V Accuracy: ± 10%	-
Resistance measurement (De-energized circuit)	-	0 Ω to 999 kΩ Range: 0 Ω to 999 Ω (resolution: 5 Ω) Range: 1 kΩ to 999 kΩ (resolution: 1 kΩ) Accuracy: ± 10%	-
Output hazardous voltage warning	-	≥ 30 V rms	-
Mains hazardous voltage warning	-	≥ 30 V rms	-
Sensitivity adjustment (gain control)	Yes	-	-
Sensitivity at 1 m (typical)	Power: 2 mA Radio: 20 μA 8 kHz: 5 μA 33 kHz: 5 μA	-	-
Display	4.3 in, 320 x 240 BW outdoor LCD display with auto backlight	LCD display (LED backlight) 2.4 in x 1.3 in	-
Update rate	Instantaneous	Current (mA): 10 ms Voltage (V): 15 ms Resistance (Ω): 330 ms	-
Operating temperature and humidity	-20 °C to 50 °C (-4 °F to 122 °F), ≤90% RH		
Storage temperature and humidity		-40 °C to 60 °C (-40 °F to 140 °F), ≤90% RH	
Operating altitude		< 2000 m (< 6561 ft)	
Pollution degree	2		
Water and dust resistance	IP54		
Drop proof Power supply	(6) 1.5 V AA alkaline batteries	1 m (3.28 ft) (8) 1.5 V D cell alkaline batteries	
Auto power off	15 minutes idle	(6) 1.5 V D cell alkaline batteries	
Battery life	Approx. 35 hours at 21 °C (70 °F) (Typical)	Approx. 16 hours at 21 °C (70 °F) (Typical)	_
Overload protection	-	600 V rms Fuse FF 500 mA, 1000 V, IR 30 kA, 6.3×32 mm	-
Certifications	۵. (۲ کی ا	. @ :: CE 💩 🕼	. @ .₀ C € ▲ ℤ
Safety compliance	IEC 61010-1, IEC 61010-2-033 CSA/UL 61010-1, CSA/UL 61010-2-033	IEC 61010-1, IEC 61010-2-033 CSA/UL 61010-1, CSA/UL 61010-2-033 IEC 61010-031, CSA/UL 61010-031 (test leads)	IEC 61010-1, IEC 61010-2-033 CSA/UL 61010-1, CSA/UL 61010-2-033
Size (H x W x L)	Approx. 302 x 120 x 779 mm (11.9 x 4.7 x 30.7 in)	Approx. 355 x 230 x 120 mm (14 x 9 x 4.7 in)	Approx. 295 x 180 x 37 mm (11.6 x 7.1 x 1.4 in)
Weight	Approx. 1.9 kg (4.2 lb) (batteries installed)	Approx. 3.2 kg (7.0 lb) (batteries installed)	Approx. 0.85 kg (1.9 lb)

Beha-Amprobe® Division of Fluke Corp. (USA) c/o Fluke Europe BV

In den Engematten 14 79286 Glottertal, Germany Tel. +49 (0) 7684 - 8009-0 info@beha-amprobe.de beha-amprobe.de Science Park Eindhoven 5110 NL-5692 EC Son The Netherlands Tel. +31 (0) 40 267 51 00 beha-amprobe.com



UAT-600-EUR Series Kits and Accessories





UAT-610-EUR Underground Utilities Locator Kit

UAT-600-EUR Series Kit contents

	UAT-610-EUR	UAT-620-EUR
UAT-600-RE Receiver	1	1
UAT-600-TE Transmitter	1	1
CC-UAT-600-EUR Carrying Case	1	1
TL-UAT-600 Test Leads Kit*	1	1
FP-UAT-600 Replacement Fuse	2	2
User Manual	1	1
Quick Reference Guide	1	1
1.5 V AA (IEC LR6) Batteries (Receiver)	6	6
1.5 V D (IEC LR20) Batteries (Receiver)	8	8
SC-600-EUR Signal Clamp	-	1

Optional Accessories

	Description	
AF-600-EUR*	A-Frame ground fault locator to pinpoint ground faults where current is leaking to ground	
BR-600-R	Rechargeable battery for Receiver	
BR-600-T	Rechargeable battery for Transmitter	
EPS-UAT-600	2-port charger for Receiver and Transmitter batteries	
TL-600-25M	Extension test lead, 25 m (80')	

* AF-600-EUR A-Frame includes: • A-Frame Receiver

(6) 1.5 V AA (IEC LR6) Batteries

Carrying Case

User Manual

*TL-UAT-600 Test Leads Kit includes:

Black test lead with detachable black alligator clip

Red test lead with permanently attached red alligator clip

Ground stake

Beha-Amprobe® Division of Fluke Corp. (USA) c/o Fluke Europe BV

In den Engematten 14 5A) 79286 Glottertal, Germany Tel. +49 (0) 7684 - 8009-0 info@beha-amprobe.de beha-amprobe.de Science Park Eindhoven 5110 NL-5692 EC Son The Netherlands Tel. +31 (0) 40 267 51 00 beha-amprobe.com