poly

HEADSET PARTS AND ACCESSORIES GUIDE

SPRING/SUMMER 2021

CONTENTS

2–15
WIRELESS HEADSET SYSTEMS

15–17
HANDSET/SPEAKERPHONE

18–21
USB CORDED HEADSETS

22–26
CORDED CALL CENTER HEADSETS

27–31
AUDIO PROCESSORS AND ADAPTERS

32–33
CABLES AND CONNECTORS USB ADAPTERS

34–60
ACCESSORIES AND PARTS FOR DISCONTINUED PRODUCTS

WIRELESS HEADSET SYSTEMS
SAVI 7200 OFFICE SERIES....2
SAVI 7300 OFFICE SERIES....3
SAVI 8200 OFFICE AND UC SERIES....5
CS540....7
CS500 XD SERIES....9
VOYAGER FOCUS 2....11
VOYAGER FOCUS UC....12
VOYAGER 4200 OFFICE AND UC SERIES....13
VOYAGER 4245 OFFICE....14
VOYAGER 5200 OFFICE AND UC SERIES....15
VOYAGER 6200 UC....16
VOYAGER 8200 UC....17

HANDSET/SPEAKERPHONE SYSTEMS
HL10 AUTOMATIC HANDSET LIFTER....18
ON-LINE INDICATOR....18
POLY SYNC 20/20+/40/60....19
PLANTRONICS STATUS INDICATOR....20
CALISTO 240....20
CALISTO 3200....20
CT14....21

USB CORDED HEADSETS
BLACKWIRE 3200 SERIES....22
BLACKWIRE 3300 SERIES....23
BLACKWIRE 5200 SERIES....24
BLACKWIRE 8225....24

CORDED CALL CENTER HEADSETS
ENCOREPRO 300 SERIES....25
ENCOREPRO 500 SERIES....26
ENCOREPRO 700 SERIES....28

AUDIO PROCESSORS AND ADAPTERS
S12....29
VISTA M22 AUDIO PROCESSOR....30
CA22CD....31
MDA220 USB....32
MDA500 QD SERIES....32
DA SERIES AUDIO PROCESSORS....33

CABLES AND CONNECTORS....34

USB ADAPTERS....35

ACCESSORIES AND PARTS FOR DISCONTINUED PRODUCTS....36
BLACKWIRE 200 SERIES....36
BLACKWIRE 300 SERIES....37
BLACKWIRE 420....37
BLACKWIRE 435/500 SERIES....38
BLACKWIRE 600 SERIES....39
BLACKWIRE 700 SERIES....39
BLACKWIRE 7225....40
CALISTO 420....40
CALISTO 600 SERIES....41
CALISTO 800 SERIES....42
CALISTO 820/830....42
CALISTO 5200/5300/7200....43
CA12CD-S....44
CS50/CS55/CS50-USB....44
CS70N....45
CS500 SERIES....46
CT12....47
DA SERIES AUDIO PROCESSORS....47
ENCOREPRO 535/ENTERA USB....48
MDA100/400 QD SERIES....49
MX10 AUDIO PROCESSOR....50
S11....50
SAVI 400 SERIES....51
SAVI 700 SERIES....53
SAVI GO....55
SAVI OFFICE....56
SUPRA/SUPRAPLUS SL....58
SUPRAPLUS WIDEBAND....59
SUPRAPLUS WIRELESS....60
VISTAPLUS AP15 AUDIO PROCESSOR....60
VOYAGER 510....61
VOYAGER 3200 UC....61
VOYAGER EDGE UC....62
VOYAGER LEGEND CS....63
VOYAGER LEGEND UC....64
VOYAGER PRO UC....65

SAVI 7200 OFFICE SERIES

Savi 7210 Office

Savi 7220 Office

IN THE BOX

SAVI 7200 OFFICE SERIES

Headset
Base unit
AC power supply
Telephone interface cable
Quick Start Guide

213351-01
213351-02

213352-01
213352-02

216758-01

SPARES AND REPLACEMENT PARTS

PART NO.	
213351-01	Spare, mon headset, DECT 6.0, Savi 7200, NA
213351-02	Spare, mon headset, DECT, Savi 7200, EU
213352-01	Spare, bin headset, DECT 6.0, Savi 7200, NA
213352-02	Spare, bin headset, DECT, Savi 7200, EU
216261-01	Spare battery Savi 7200 with removal tool, *not shown*
216758-01	Spare ear cushion Savi 7200 (1 piece)

37818-11

37820-11

38350-13

38439-11

38633-11

38734-11

60961-35

78887-01

87317-01

87327-01
201081-01

89280-11

202578-01

211076-01

212539-01

CABLES AND CONNECTORS FOR REMOTE DESK PHONE CALL CONTROL

37818-11	APS-11, Electronic Hook Switch, Siemens®/Funwerk®/Auerswald®/ Agfeo®/Aastra®/DeTeWe®
37820-11	APT-31, Electronic Hook Switch, Avaya® GmbH (Tenovis)
38350-13	APC-43, Electronic Hook Switch, Cisco
38439-11	APP-51, Electronic Hook Switch, Poly
38633-11	APV-66, Electronic Hook Switch, Avaya (EU24)
38734-11	APV-63, Electronic Hook Switch, Avaya
60961-35	HL10 handset lifter, Straight Plug
78887-01	RD-1 Electronic Hook Switch, Shoretel®/Toshiba®/ Adtran®/Allworx® (not available in Europe)
85638-01	EHS Extension Cable, Cisco, *not shown*
87317-01	APC-45, Electronic Hook Switch, Cisco
87327-01	APD-80, Electronic Hook Switch
89280-11	APN-91, Electronic Hook Switch, NEC®
201081-01	APC-82, Electronic Hook Switch, Cisco
202578-01	APU-72, Electronic Hook Switch, Avaya (Nortel®)/Cisco
211076-01	APU-76 EHS Cable
212539-01	APA-24 Alcatel EHS Cable

Savi 7310 Office

Savi 7320 Office

IN THE BOX

SAVI 7300 OFFICE SERIES

Headset
Base unit
AC power supply
Telephone interface cable
USB-A cable
USB-C cable
Quick Start Guide

214558-01
214558-02

217403-01
217403-05
217403-08
217403-10
217403-101

217411-01
217411-05
217411-08
217411-10
217411-101

217412-01
217412-05
217412-08
217412-10
217412-101

SPARES AND REPLACEMENT PARTS

PART NO.	
214558-01	Spare ear cushion Savi 7310 (1 piece)
214558-02	Spare ear cushions Savi 7320 (2 pieces)
217400-01	Spare, battery, Savi 7300 Series, with removal tool, *not shown*
217402-01	Spare, Savi 7310, headset, DECT 6.0, NA, *not shown*
217402-05	Spare, Savi 7310, headset, DECT, EMEA, *not shown*
217402-08	Spare, Savi 7310, headset, DECT, AU/NZ, *not shown*
217402-10	Spare, Savi 7310, headset, DECT, Brazil, *not shown*
217402-101	Spare, Savi 7310, headset, DECT, JDECT, *not shown*
217403-01	Spare, Savi 7320, headset, DECT 6.0, NA
217403-05	Spare, Savi 7320, headset, DECT, EMEA
217403-08	Spare, Savi 7320, headset, DECT, AU/NZ
217403-10	Spare, Savi 7320, headset, DECT, Brazil
217403-101	Spare, Savi 7320, headset, DECT, JDECT
217411-01	Spare, Savi 7310-M, headset, DECT 6.0, NA
217411-05	Spare, Savi 7310-M, headset, DECT, EMEA
217411-08	Spare, Savi 7310-M, headset, DECT, AU/NZ
217411-10	Spare, Savi 7310-M, headset, DECT, Brazil
217411-101	Spare, Savi 7310-M, headset, DECT, JDECT
217412-01	Spare, Savi 7320-M, headset, DECT 6.0, NA
217412-05	Spare, Savi 7320-M, headset, DECT, EMEA
217412-08	Spare, Savi 7320-M, headset, DECT, AU/NZ
217412-10	Spare, Savi 7320-M, headset, DECT, Brazil
217412-101	Spare, Savi 7320-M, headset, DECT, JDECT

SAVI 7300 OFFICE SERIES CONTINUED

37818-11

37820-11

38350-13

38439-11

38633-11

38734-11

60961-35

78887-01

87317-01

87327-01
201081-01

89280-11

202578-01

211076-01

212539-01

CABLES AND CONNECTORS FOR REMOTE DESK PHONE CALL CONTROL

37818-11	APS-11, Electronic Hook Switch, Siemens®/Funwerk®/Auerswald®/ Agfeo®/Aastra®/DeTeWe®
37820-11	APT-31, Electronic Hook Switch, Avaya® GmbH (Tenovis)
38350-13	APC-43, Electronic Hook Switch, Cisco
38439-11	APP-51, Electronic Hook Switch, Poly
38633-11	APV-66, Electronic Hook Switch, Avaya (EU24)
38734-11	APV-63, Electronic Hook Switch, Avaya
60961-35	HL10 handset lifter, Straight Plug
78887-01	RD-1 Electronic Hook Switch, Shoretel®/Toshiba®/ Adtran®/Allworx® (not available in Europe)
85638-01	EHS Extension Cable, Cisco, *not shown*
87317-01	APC-45, Electronic Hook Switch, Cisco
87327-01	APD-80, Electronic Hook Switch
89280-11	APN-91, Electronic Hook Switch, NEC®
201081-01	APC-82, Electronic Hook Switch, Cisco
202578-01	APU-72, Electronic Hook Switch, Avaya (Nortel®)/Cisco
211076-01	APU-76 EHS Cable
212539-01	APA-24 Alcatel EHS Cable

SAVI 8200 OFFICE AND UC SERIES

Savi 8210 Office

Savi 8220 Office

Savi 8240 Office

Savi 8245 Office

Savi 8210 UC

Savi 8220 UC

Savi 8240 UC

Savi 8245 UC

IN THE BOX

SAVI 8210 OFFICE/SAVI 8220 OFFICE
Headset
Quick Start Guide
Base unit
Micro to USB PC cable
AC charger and pins
Charging cradle
Telephone interface cable

SAVI 8240 OFFICE/SAVI 8245 OFFICE
Headset
Headband
Neckband
Charging cradle
Base unit
Convertible fit kit
AC charger and pins
Telephone interface cable
Micro to USB PC cable

SAVI 8210 UC
Headset
D200 USB adapter
AC power supply
Charging base
Carry case
USB-C cable
Quick Start Guide

SAVI 8220 UC
Headset
D200 USB adapter
AC power supply
Charging base
Carry case
USB-C cable
Quick Start Guide

SAVI 8240 UC
Headset + battery
Headband
Neckband
Ear loop
Headset fit kit
Charging cradle
D200 USB adapter
AC power supply
Charging base
Carry case
USB charging cable
Quick Start Guide

SAVI 8245 UC
Headset + battery
Headband
Neckband
Ear loop
Headset fit kit
Charging cradle
D200 USB adapter
AC power supply
Charging base
Carry case
USB deluxe charging cable
Spare battery
Quick Start Guide

84605-01

84606-01

86079-01

211044-01

211423-01
211423-03

211423-02
211423-04

211424-01

211425-01
213199-01

217391-01

SPARES AND REPLACEMENT PARTS

PART NO.	
84605-01	Headband
84606-01	Neckband
86007-01	Telephone interface cable, *not shown*
86079-01	AC power supply, straight plug (universal)
87229-01	Ear cushions
211044-01	Spare, charge base, 5 units, 3 pins, Savi 8200 Series
211423-01	Spare, headset & Charging cradle, W8210, AMER
211423-02	Spare, headset & Charging cradle, W8220, AMER
211423-03	Spare, headset & Charging cradle, W8210, E&A, APME
211423-04	Spare, headset & Charging cradle, W8220, E&A, APME
211424-01	Spare, ear cushions, W8210, W8220
211425-01	Spare, battery W8210 (mono) with removal tool
212675-01	Spare cable USB-C to Micro USB-B, *not shown*
213199-01	Spare, battery W8220 (stereo) with removal tool
217391-01	Charging base, Savi 8210/8220 UC

SAVI 8200 OFFICE AND UC SERIES CONTINUED

211500-01

215800-01

215801-01

215802-01

215803-01

215804-01

209850-04

SPARES AND REPLACEMENT PARTS CONTINUED

PART NO.	
211500-01	Charging cradle, Savi 8210, Savi 8220
215800-01	Spare headset, Charging cradle and fit kit, Savi 8240/8245, NA
215801-01	Spare headset, Charging cradle and fit kit, Savi 8240/8245, E&A
215802-01	Spare battery Savi 8240/8245
215803-01	Spare Charging cradle, Savi 8240
215804-01	Spare Charging cradle, Savi 8245
215805-01	Spare Charging cradle, Savi 8245 + battery, *not shown*
215806-01	Spare ear loops/ear gels, *not shown*
216100-01	USB charger Savi 8240/8245, *not shown*

D200 SPARES

209200-01	D200 USB-A, Savi, adapter, DECT 6.0, NA, *not shown*
209200-02	D200 USB-A, Savi, adapter, DECT, UK/EURO/AUS/NZ, *not shown*
209200-03	D200 USB-A, Savi, adapter, MOC, DECT 6.0, NA, *not shown*
209200-04	D200 USB-A, Savi, adapter, MOC, DECT, UK/EURO/AUS/NZ, *not shown*
209850-01	D200 USB-C, Savi, adapter, DECT 6.0, NA, *not shown*
209850-02	D200 USB-C, Savi, adapter, DECT, UK/EURO/AUS/NZ, *not shown*
209850-03	D200 USB-C, Savi, adapter, MOC, DECT 6.0, NA, *not shown*
209850-04	D200 USB-C, Savi, Adapter, MOC, DECT, UK/EURO/AUS/NZ

37820-11

38350-13

38439-11

38633-11

38734-11

60961-35

78887-01

211076-01

212539-01

CABLES AND CONNECTORS FOR REMOTE DESK PHONE CALL CONTROL

37818-11	APS-11, Electronic Hook Switch, Siemens®/Funwerk®/Auerswald®/Agfeo®/ Aastra®/DeTeWe®, *not shown*
37820-11	APT-31, Electronic Hook Switch, Avaya® GmbH (Tenovis)
38350-13	APC-43, Electronic Hook Switch, Cisco
38439-11	APP-51, Electronic Hook Switch, Poly
38633-11	APV-66, Electronic Hook Switch, Avaya (EU24)
38734-11	APV-63, Electronic Hook Switch, Avaya
60961-35	HL10™ Handset lifter, straight plug
78887-01	RD-1 Electronic Hook Switch, Shoretel®/Toshiba®/ Adtran®/Allworx® (not available in Europe)
85638-01	EHS extension cable, Cisco, *not shown*
87317-01	APC-45, Electronic Hook Switch, *image on page 8*
87327-01	APD-80, Electronic Hook Switch, *image on page 8*
89280-11	APN-91, Electronic Hook Switch, NEC®, *image on page 8*
201081-01	APC-82, Electronic Hook Switch, Cisco, *image on page 8*
202578-01	APU-72, Electronic Hook Switch, Avaya (Nortel®)/Cisco, *image on page 8*
211076-01	APU-76 EHS cable
212539-01	APA-24 Alcatel EHS cable

CS540

IN THE BOX

CS540
Headset and battery
AC power supply
Headband
Telephone interface cable
Headset fit kit
Quick Start Guide
Base

SPARES AND REPLACEMENT PARTS

81423-01

84604-01

84605-01

86007-01

86179-01

86180-01

86540-01

PART NO.	
81423-01	AC power supply, straight plug
84604-01	Fit kit, earloops/earbuds/foam ear loop cover (CS540)
84605-01	Headband (CS540)
86007-01	Telephone interface cable
86179-01	Convertible headset (CS540 DECT 6.0, NA)
86179-02	Convertible headset (CS540) DECT EMEA
86180-01	Battery (CS540) with part number 84479-01 marked on battery
86180-02	Battery (CS540) for units sold in EMEA after August 2020 with part number 212367-01 marked on battery, *not shown*
86540-01	Eartips, earloops (CS540)

80287-01

84606-01

ACCESSORIES

65116-02	On-Line indicator light, *not shown*
80287-01	On-line indicator, straight plug
84606-01	Neckband (CS540)
87527-01	Foam ear loop covers, 20 units (CS540), *image on page 8*
88940-01	Spare eartips, 25 units, small (CS540), *image on page 8*
88941-01	Spare eartips, 25 units, medium (CS540), *image on page 8*

84599-01

84609-01

86005-01

HEADSET CHARGING ACCESSORIES FOR MULTI-SHIFT ENVIRONMENTS

84599-01	Standard Charging cradle - charging only (CS540)
84609-01	Charge base, 5 units, 3 pins (with AC power supply)
86005-01	Charge base, 1 unit, 3 pins (with AC power supply)

37818-11
37820-11

38350-13

38439-11

38633-11

38734-11

60961-35

78887-01

87317-01

87327-01

202578-01

211076-01

212539-01

CABLES AND CONNECTORS FOR REMOTE DESK PHONE CALL CONTROL

PART NO.	
37818-11	APS-11, Electronic Hook Switch, Siemens®/Funwerk®/Auerswald®/ Agfeo®/Aastra®/DeTeWe®
37820-11	APT-31, Electronic Hook Switch, Avaya® GmbH (Tenovis)
38350-13	APC-43, Electronic Hook Switch, Cisco
38439-11	APP-51, Electronic Hook Switch, Poly
38633-11	APV-66, Electronic Hook Switch, Avaya (EU24)
38734-11	APV-63, Electronic Hook Switch, Avaya
60961-35	HL10 handset lifter, straight plug
78887-01	RD-1 Electronic Hook Switch, Shoretel®/Toshiba®/ Adtran®/Allworx® (not available in Europe)
85638-01	EHS extension cable, Cisco, *not shown*
87317-01	APC-45, Electronic Hook Switch, Cisco
87327-01	APD-80, Electronic Hook Switch
89280-11	APN-91, Electronic Hook Switch, NEC®, *image on page 8*
201081-01	APC-82, Electronic Hook Switch, Cisco, *image on page 8*
202268-01	API-28, Electronic Hook Switch, Apple iPhones
202578-01	APU-72, Electronic Hook Switch, Avaya (Nortel®)/Cisco
211076-01	APU-76 EHS cable
212539-01	APA-24 Alcatel EHS cable

CS545-XD™, Convertible+ Deluxe Charging Kit

CS540-XD™, Convertible

CS520-XD

CS510-XD

IN THE BOX

CS545-XD

Headset and battery base
Headband
Headset fit kit
AC power supply
Telephone interface cable
Other size eartips and earloops
Telephone interface cable
Second battery charger with spare battery and AC power
Quick Start Guide

CS540-XD

Headset and battery
Base
Headband
Headset fit kit
AC power supply
Telephone interface cable
Quick Start Guide

CS520-XD

Headset
Base
AC power supply
Telephone interface cable
Quick Start Guide

CS510-XD

Headset
Base
AC power supply
Telephone interface cable
Quick Start Guide

71782-01

81423-01

84598-01

84604-01

84605-01

84606-01

86007-01

86540-01

89547-01

89548-01

89549-01

89806-01

SPARES AND REPLACEMENT PARTS

PART NO.	
71782-01	Ear cushions, leatherette (2) (CS510-XD/CS520-XD)
72742-02	Headband Support (CS510-XD/CS520-XD), *image on page 43*
81423-01	AC power supply, straight plug
84598-01	CS spare battery (CS540XD/CS545XD)
84604-01	Fit kit, earloops/earbuds/foam ear loop cover (CS540-XD/CS545-XD)
84605-01	Headband (CS540-XD/CS545-XD)
84606-01	Neckband (CS540-XD/CS545-XD)
86007-01	Telephone interface cable
86540-01	Eartips, Earloops (CS540-XD/CS545-XD)
88286-01	Spare battery charging cable and AC adapter, *not shown*
89525-01	Spare Battery Charging Cable, *not shown*
89547-01	Headset (CS510-XD)
89548-01	Headset (CS520-XD)
89549-01	Over-the-ear Headset (CS540-XD/CS545-XD)
89804-01	Spare battery charging cable and battery, *not shown*
89806-01	Spare battery charging cable, AC adapter and battery (CS545-XD)
202599-03	CS510/520 Battery, *not shown*

CS500 XD SERIES CONTINUED

71781-01

80287-01

87527-01

88940-01

88941-01

83776-11

84599-01

84609-01

86005-01

37818-11

37820-11

38350-13

38439-11

38633-11

38734-11

60961-35

78887-01

87317-01

87327-01
201081-01

89280-11

202578-01

211076-01

212539-01

ACCESSORIES

PART NO.	
65116-02	On-Line indicator light, *image on page 41*
71781-01	Foam ear cushions (CS510-XD/CS520-XD)
80287-01	On-line indicator, straight plug
87527-01	Foam ear loop covers, 20 Units (CS540-XD/CS545-XD)
88940-01	Spare eartips, 25 units, small (CS540-XD/CS545-XD)
88941-01	Spare eartips, 25 units, medium (CS540-XD/CS545-XD)

HEADSET CHARGING ACCESSORIES FOR MULTI-SHIFT ENVIRONMENTS

83776-11	Over-the-head Charging cradle (CS510-XD/CS520-XD)
84598-01	Battery (CS540-XD), *not shown*
84599-01	Standard Charging cradle - charging only (CS540-XD)
84600-01	Deluxe Charging cradle (C540XD/545XD), *not shown*
84609-01	Charge base, 5 units (recommend for CS540XD/CS545XD)
86005-01	Charge base, 1 unit, 3 pins with AC power supply (recommend for CS540XD/CS545XD)

CABLES AND CONNECTORS FOR REMOTE DESK PHONE CALL CONTROL

37818-11	APS-11, Electronic Hook Switch, Siemens®/Funwerk®/Auerswald®/ Agfeo®/Aastra®/DeTeWe®
37820-11	APT-31, Electronic Hook Switch, Avaya® GmbH (Tenovis)
38350-13	APC-43, Electronic Hook Switch, Cisco
38439-11	APP-51, Electronic Hook Switch, Poly
38633-11	APV-66, Electronic Hook Switch, Avaya (EU24)
38734-11	APV-63, Electronic Hook Switch, Avaya
60961-35	HL10 handset lifter, Straight Plug
78887-01	RD-1 Electronic Hook Switch, Shoretel®/Toshiba®/ Adtran®/Allworx® (not available in Europe)
85638-01	EHS Extension Cable, Cisco, *not shown*
87317-01	APC-45, Electronic Hook Switch, Cisco
87327-01	APD-80, Electronic Hook Switch
89280-11	APN-91, Electronic Hook Switch, NEC®
201081-01	APC-82, Electronic Hook Switch, Cisco
202578-01	APU-72, Electronic Hook Switch, Avaya (Nortel®)/Cisco
211076-01	APU-76 EHS Cable
212539-01	APA-24 Alcatel EHS Cable

Voyager Focus 2 UC

Voyager Focus 2 Office

IN THE BOX

VOYAGER FOCUS 2 UC

Headset
Bluetooth® adapter (USB-A or USB-C)
Charging cable
Carry case
Charge stand* (USB-A or USB-C)
User guide
*Included with certain models only

VOYAGER FOCUS 2 OFFICE

Headset
AC adapter
Telephone interface cable
USB-A cable
Carry case
User guide

SPARES AND REPLACEMENT PARTS

215476-01

219298-01

217877-01

217878-01

PART NO.	
Coming soon	Spare carry case
Coming soon	Spare Ear cushions
Coming soon	Charge Stand, USB-A
Coming soon	Charge Stand, USB-C
217877-01	BT700 USB adapter
217878-01	BT700 USB-C, boxed

220265-01
220265-02

VOYAGER FOCUS UC

Voyager Focus UC

IN THE BOX

VOYAGER FOCUS UC
Headset
Desktop charging stand
Mini Bluetooth® USB adapter
Carrying case
Micro USB charge cable

204880-01
205250-01

205300-01

205301-01

205302-01

211249-01
211002-01

213121-01

SPARES AND REPLACEMENT PARTS

PART NO.	
204880-01	BT600 USB adapter, boxed (EMEA part number)
205250-01	BT600 USB adapter, boxed
205300-01	Leatherette ear cushions, (2)
205301-01	Carrying case
205302-01	Desktop charge stand
211249-01	BT600 USB-C, boxed
211002-01	BT600 USB-C, in a bag
213121-01	Spare, cable assembly, STD-A plug to micro USB-B, 1500 mm

89034-01

ACCESSORIES

89034-01	AC charger (NA only)

VOYAGER 4200 OFFICE AND UC SERIES

Voyager 4210 UC

Voyager 4220 UC

Voyager 4210 Office, 1-Way Base

Voyager 4220 Office, 2-Way Base

IN THE BOX

VOYAGER 4210 UC/VOYAGER 4220 UC

Headset
Bluetooth adapter: BT600 USB-A or USB-C variant
Carrying case
Charging cable: USB-A or USB-C to micro USB
Warranty card
Quick Start Guide

VOYAGER 4200 OFFICE

Headset
Base unit D or CD
Quick Start Guide
Carry pouch
AC adapter
Telephone interface cable
PC cable USB-A, USB-C
Charge stand

86007-01

86079-01

89034-01

204880-01
205250-01

211249-01

213119-01

213121-01

213365-01

213546-01
213546-02

ACCESSORIES

PART NO.	
86007-01	Telephone interface cable
86079-01	AC power supply, straight plug (universal)
89034-01	AC charger (NA only)
204880-01	BT600 USB adapter, boxed (EMEA part number)
205250-01	BT600 USB adapter, boxed
211249-01	BT600 USB-C, boxed
213119-01	Spare, pouch, Voyager
213121-01	Spare, cable assembly, STD-A plug to micro USB-B, 1500 mm
213122-01	Spare, USB cable, type C – USB, 1500 mm (black), Voyager, *not shown*
213364-01	Spare, ear cushion mono, Voyager 4210, *not shown*
213365-01	Spare, ear cushion bina, Voyager 4220
213546-01	Spare, charge stand type A, Voyager 4220, WW
213546-02	Spare, charge stand type C, Voyager 4220, WW

WIRELESS HEADSET SYSTEMS

VOYAGER 4245 OFFICE

Voyager 4245 Office

IN THE BOX

VOYAGER 4245 OFFICE
Headset and battery
Headband
Neckband
Headset fit kit
Base
AC power supply
USB charging cable
Spare battery
Telephone interface cable
Quick Start Guide

84604-01

84605-01

84606-01

86006-01

86007-01

86079-01

87229-01

87527-01

88940-01

88941-01

SPARES AND ACCESSORIES

PART NO.	
84604-01	Fit kit (Savi 440)
84605-01	Headband (Savi 440)
84606-01	Neckband (Savi 440)
86006-01	Hard carrying case (Savi 430/Savi 440)
86007-01	Telephone interface cable
86079-01	AC power supply, straight plug (universal)
87229-01	Ear cushions (Savi 440)
87527-01	Foam ear loop covers (20 units) (Savi 440)
88940-01	Spare eartips (25 units) (Savi 440) Small
88941-01	Spare eartips (25 units) (Savi 440) Medium
215802-01	Spare battery, *not shown*

VOYAGER 5200 OFFICE AND UC SERIES

Voyager 5200 UC

Voyager 5200 Office, 1-Way Base

Voyager 5200 Office, 2-Way Base

IN THE BOX

VOYAGER 5200 UC
Headset and eartips
Mini USB Bluetooth® adapter
Portable charging case
USB charging cable
Quick Start Guide

VOYAGER 5200 OFFICE
Headset
Eartips
Base unit D or CD
Quick Start Guide
AC adapter
Telephone interface cable
PC cable USB-A, USB-C

86007-01

86079-01

203710-01
203710-02

203710-03

204500-01

204880-01
205250-01

211249-01
211002-01

SPARES AND REPLACEMENT PARTS

PART NO.	
86007-01	Telephone interface cable
86079-01	AC power supply, straight plug (universal)
89037-01	Black eartips, *not shown*
203710-01	Small, 3-pack, eartips/foam eartip covers
203710-02	Medium, 3-pack, eartips/foam eartip covers
203710-03	Large, 3-pack, eartips
204500-01	Portable charge case (includes micro USB charge cable, 2')
204880-01	BT600 USB adapter, boxed (EMEA part number)
205250-01	BT600 USB adapter, boxed
211249-01	BT600 USB-C, boxed
211002-01	BT600 USB-C, in a bag

89034-01

89110-01

213121-01

ACCESSORIES

89034-01	AC charger (NA only)
89110-01	USB car charger
213121-01	Spare, cable assembly, STD-A plug to micro USB-B, 1500 mm

VOYAGER 6200 UC

Voyager 6200 UC

IN THE BOX

VOYAGER 6200 UC
Headset
Carrying case
BT600 USB adapter
Quick Start Guide
Micro USB cable
Desktop charge stand
Large and small ear tips

201885-01

211149-01
211149-02
211149-03

211149-04

211149-05

204880-01
205250-01

211249-01
211002-01

SPARES AND REPLACEMENT PARTS

PART NO.	
201885-01	Micro USB charging cable
211149-01	Ear tips, small
211149-02	Ear tips, medium
211149-03	Ear tips, large
211149-04	Carrying case
211149-05	Desktop charging stand
204880-01	BT600 USB adapter, boxed (EMEA part number)
205250-01	BT600 USB adapter, boxed
211249-01	BT600 USB-C, boxed
211002-01	BT600 USB-C, in a bag

89034-01

89110-01

ACCESSORIES

89034-01	AC charger (NA only)
89110-01	USB car charger

Voyager 8200 UC, black

IN THE BOX

VOYAGER 8200 UC
Headset
Carrying pouch
USB charge cable
Product card
3.5 mm cable
Safety booklet
BT600 USB adapter
Warranty card

209179-01

204880-01
205250-01

209088-01

211249-01
211002-01

213121-01

215694-01

SPARES AND REPLACEMENT PARTS

PART NO.	
209179-01	3.5 mm cable
204880-01	BT600 USB adapter, boxed (EMEA part number)
205250-01	BT600 USB adapter, boxed
204880-01	BT600 USB adapter, in a bag, *not shown*
209088-01	Soft Carrying case
211002-01	BT600 USB-C, in a bag
211249-01	BT600 USB-C, boxed
213121-01	Spare, cable assembly, STD-A plug to micro USB-B, 1500 mm
215694-01	Spare ear cushions, black, Voyager 8200 UC

89034-01

89110-01

ACCESSORIES

89034-01	AC charger (NA only)
89110-01	USB car charger

HL10 AUTOMATIC HANDSET LIFTER

HL10

IN THE BOX

Handset lifter
Extension arm/ring detector kit
Mounting tape
User guide

60961-35

71483-01

SPARES AND REPLACEMENT PARTS

PART NO.	
60961-35	HL10 handset lifter, straight plug
61578-01	Mounting tape, *not shown*
71483-01	Extension arm/ring detector kit for Nortel i2004 phones

**Needed for Nortel M3900 Series and several other manufacturers' phones*

ON-LINE INDICATOR*

On-line Indicator

IN THE BOX

On-line indicator
Mounting tape

46429-01

80287-01

SPARES AND REPLACEMENT PARTS

PART NO.	
46429-01	Extension cable
80287-01	On-line indicator, straight plug
92605-01	On-line indicator adapter (3.5 mm splitter cable), *not shown*

**Works with Savi 700 Series/Savi 8200 Office/Savi 7200 Office Series/CS500/ CS500 XD Series and Voyager Legend CS*

POLY SYNC 20/POLY SYNC 20+

Poly Sync 20

IN THE BOX

POLY SYNC 20

Travel case
Lanyard
User guide
BT600 (Poly Sync 20+ only)

204880-01
205250-01

218427-01

ACCESSORIES

PART NO.	
204880-01	BT600 USB adapter, boxed (EMEA part number)
205250-01	BT600 USB Adapter
211249-01	BT600C USB Adapter, *not shown*
218427-01	Poly Sync 20 Travel Case

POLY SYNC 40

Poly Sync 40

IN THE BOX

POLY SYNC 40

User guide

204880-01
205250-01

218430-01

ACCESSORIES

PART NO.	
204880-01	BT600 USB adapter, boxed (EMEA part number)
205250-01	BT600 USB Adapter
211249-01	BT600C USB Adapter, *not shown*
218429-01	Poly Sync 40 desk mount, *not shown*
218430-01	Poly Sync 40 charge stand

POLY SYNC 60

Poly Sync 60

IN THE BOX

POLY SYNC 60

User guide

PLANTRONICS STATUS INDICATOR

Plantronics Status Indicator

IN THE BOX

Plantronics Status Indicator
5 ft micro USB cable
3M double-sided sticker
Getting Started insert

CALISTO 240

Calisto 240

IN THE BOX

Handset
Cloth carrying pouch
Desktop stand

89339.000

SPARES

PART NO.	
89339.000	Desktop stand

CALISTO 3200

Calisto 3200

IN THE BOX

Calisto 3200
Carrying case
Quick Start Guide
Compliance insert
Warranty card
Safety Guide

211035-01

ACCESSORIES

PART NO.	
211035-01	Carrying bag, Calisto 3200

CT14

IN THE BOX

Handset and Battery
Headband
Belt clip
Charging base
Headset
AC power supply
Earloop
Landline Telephone cable
Ear cushion
User Guide

43298-03

45650-03

46186-01

81079-02

81082-01

81083-01

81085-01

81086-01

81087-02

SPARES AND REPLACEMENT PARTS

PART NO.	
43298-03	Headband
45650-03	Spare ring/pivot ball assembly
46186-01	Ear cushion, leatherette
81079-02	AC power supply (CT14)
81082-01	Landline Telephone cable
81083-01	Headset
81085-01	Battery door
81086-01	Belt clip
81087-02	Handset battery

BLACKWIRE 3200 SERIES

Blackwire 3210

Blackwire 3215

Blackwire 3220

Blackwire 3225

IN THE BOX

BLACKWIRE 3210
Headset
User Guide

BLACKWIRE 3215
Headset
Carrying case
User Guide

BLACKWIRE 3220
Headset
User Guide

BLACKWIRE 3225
Headset
Carrying case
User Guide

89862-01

88225-01

85697-01

200070-01

SPARES AND REPLACEMENT PARTS

PART NO.	
89862-01	Leatherette ear cushion (Blackwire 3215, Blackwire 3225)
88225-01	Foam ear cushion (Blackwire 3210, Blackwire 3220)
85697-01	Clothing clip
200070-01	Carrying case
211057-01	Blackwire 3215 top, *not shown*
211058-01	Blackwire 3225 top, *not shown*
211059-01	Blackwire 3200 USB-A inline, *not shown*
211060-01	Blackwire 3200 USB-C inline, *not shown*

Blackwire 3310

Blackwire 3315

Blackwire 3320

Blackwire 3325

IN THE BOX

Headset
Carrying case (Blackwire 3315, Blackwire 3325)
Quick Start Guide

215818-01

215819-01

215820-01

215821-01

216898-01

216899-01

218433-01

218524-01

SPARES AND REPLACEMENT PARTS

PART NO.	
215818-01	Spare inline control USB-A (Blackwire 3300)
215819-01	Spare inline control USB-C (Blackwire 3300)
215820-01	Spare inline control USB-A (Blackwire 3300-M)
215821-01	Spare inline control USB-C (Blackwire 3300-M)
216898-01	Spare mono headset (Blackwire 3315)
216899-01	Spare stereo headset (Blackwire 3325)
218433-01	Spare foam cushions (Blackwire 3310/3320)
218523-01	Spare leatherette cushions (Blackwire 3315/3325), *not shown*
218524-01	Spare carry case

BLACKWIRE 5200 SERIES

Blackwire 5210

Blackwire 5220

IN THE BOX

BLACKWIRE 5210	BLACKWIRE 5220
Headset	Headset
Carrying case	Carrying case
User Guide	User Guide

200070-01

208927-01

SPARES AND REPLACEMENT PARTS

PART NO.	
200070-01	Blackwire soft carrying case
208927-01	Leatherette ear cushions, (2)
211008-01	Blackwire 5210 top, *not shown*
211008-02	Blackwire 5220 top, *not shown*
211019-01	Blackwire 5200 USB-A inline, *not shown*
211019-02	Blackwire 5200 USB-C inline, *not shown*

BLACKWIRE 8225

Blackwire 8225

IN THE BOX

Headset
Travel case
User guide

213440-01

SPARES AND REPLACEMENT PARTS

PART NO.	
213440-01	Travel case
217347-01	Spare, Ear cushions, leatherette, Blackwire 8225 (2 pieces)
217446-01	

EncorePro 310 QD

EncorePro 320 QD

EncorePro 310 USB

EncorePro 320 USB

IN THE BOX

Headset
Quick Start Guide

24460-01

38300-25

40709-02

SPARES

PART NO.	
24460-01	Clothing clip
38300-25	Ear cushion (25 bulk)
40709-02	Ear cushions

27019-01
27019-03

27708-01

40703-01

62976-01

200070-01

ACCESSORIES (ENCOREPRO QD VERSIONS ONLY)

27019-01	Y-Adapter Trainer Cord, with Microphone Mute Switch and QD Clamp (EMEA part number)
27019-03	Y-Adapter Trainer Cord, with Microphone Mute Switch and QD Clamp
27708-01	Mute Switch, QD In-line
40703-01	Cable Assy., Coil, Ext., spare
62976-01	QD Cord Lock
200070-01	Spare carrying case

ENCOREPRO 500 SERIES

EncorePro 510

EncorePro 510 Voice Tube

EncorePro 510 Digital

EncorePro 515 USB

EncorePro 520

EncorePro 520 Voice Tube

EncorePro 520 Digital

EncorePro 525 USB

IN THE BOX

ENCOREPRO 510
Headset
User Guide

ENCOREPRO 510 DIGITAL
Headset
User Guide

ENCOREPRO 515 USB
Headset
User Guide

ENCOREPRO 520
Headset
User Guide

ENCOREPRO 520 DIGITAL
Headset
User Guide

ENCOREPRO 525 USB
Headset
User Guide

202118-01

202997-02

24460-01

SPARES AND REPLACEMENT PARTS

PART NO.	
202118-01	Spare voice tube
202997-02	Spare foam cushion (2)
24460-01	Clothing clip

10757-00

27019-01
27019-03

27708-01

38733-01

38733-03

40703-01

49323-46

62976-01

66268-03

79694-11

200070-01

202999-02

ACCESSORIES

10757-00	Background noise suppressor (EncorePro 510 voice tube/Encore Pro 520 voice tube)
26716-01	Cable, coil, QD-to-modular phone jack (audio processor), *shown on page 25*
27019-01	Y-Adapter Trainer Cord, with Microphone Mute Switch and QD Clamp (EMEA part number)
27019-03	Y-adapter trainer cord, with microphone mute switch and QD clamp
27708-01	Mute switch, QD in-line
38733-01	6-4 pin adapter
38733-03	4-6 pin adapter with lock (DA90)
40703-01	Cable assy., coil, ext., spare
49323-46	HIC-10
62976-01	QD cord lock
66268-03	A10 direct connect cable
79694-11	6-pin Y training adapter cable (EncorePro 510 Digital/Encore Pro 520 Digital)
200070-01	Spare carrying case
202999-02	Spare leatherette cushion (2)

EncorePro 530

EncorePro 530 Digital

EncorePro 540

EncorePro 540 Digital

EncorePro 545 USB

IN THE BOX

ENCOREPRO 530
Headset — User Guide

ENCOREPRO 530 DIGITAL
Headset — User Guide

ENCOREPRO 540
Headset — User Guide

ENCOREPRO 540 DIGITAL
Headset — User Guide

ENCOREPRO 545 USB
Headset — User Guide

24460-01

88814-01

88815-01

88816-01

88817-01

SPARES AND REPLACEMENT PARTS

PART NO.	
24460-01	Clothing clip
88814-01	Spare earloop (small and large)
88815-01	Spare neckband (EncorePro 540)
88816-01	Spare headband (EncorePro 540)
88817-01	Spare foam cushions foam

26716-01

27019-01
27019-03

27708-01

38733-01

38733-03

40703-01

49323-46

66268-03

79694-11

88832-01

88833-01

202999-02

ACCESSORIES (ENCOREPRO QD VERSIONS ONLY)

26716-01	Cable, coil, QD-to-modular phone jack (audio processor)
27019-01	Y-Adapter Trainer Cord, with Microphone Mute Switch and QD Clamp (EMEA part number)
27019-03	Y-Adapter trainer cord, with microphone mute switch and QD clamp
27708-01	Mute switch, QD in-line
38733-01	6-4 pin adapter
38733-03	4-6 pin adapter with lock (DA90)
40703-01	Cable assy., coil, ext., spare
49323-46	HIC-10
62976-01	QD cord lock, *image on page 24*
66268-03	A10 Direct connect cable
79694-11	6-pin Y training adapter cable (EncorePro 530 Digital/EncorePro 540 Digital)
88832-01	Spare leatherette cushion (large) (EncorePro 540)
88833-01	Spare leatherette cushion (small) (EncorePro 530/EncorePro 540)
200070-01	Spare carrying case

ENCOREPRO 700 SERIES

EncorePro 710

EncorePro 710 Digital

EncorePro 715 USB

EncorePro 720

EncorePro 720 Digital

EncorePro 725 USB

IN THE BOX

ENCOREPRO 710
Headset — Carrying case
User Guide

ENCOREPRO 710 DIGITAL
Headset — Carrying case
User Guide

ENCOREPRO 715 USB
Headset — Carrying case
User Guide

ENCOREPRO 720
Headset — Carrying case
User Guide

ENCOREPRO 720 DIGITAL
Headset — Carrying case
User Guide

ENCOREPRO 725 USB
Headset — Carrying case
User Guide

24460-01

80355-01

49323-46

SPARES AND REPLACEMENT PARTS

PART NO.	
24460-01	Clothing clip
80355-01	Ear cushions, leatherette (2)
49323-46	HIC-10

10778-01

26716-01

27019-01
27019-03

27708-01

38733-01

38733-03

40711-01

62976-01

66268-03

79694-11

80354-01

203009-01

ACCESSORIES (ENCOREPRO QD VERSIONS ONLY)

10778-01	Quick Disconnect™ (QD) cord clip
26716-01	Cable, coil, QD-to-modular phone jack (audio processor)
27019-01	Y-Adapter Trainer Cord, with Microphone Mute Switch and QD Clamp (EMEA part number)
27019-03	Y-Adapter trainer cord, with microphone mute switch and QD clamp
27708-01	Mute switch, QD in-line
38733-01	6-4 pin adapter
38733-03	4-6 pin adapter with lock (DA90)
40711-01	Cable, 10 ft extension, QD-to-QD lightweight
62976-01	QD cord lock
66268-03	A10 Direct connect cable
79694-11	6-Pin Y training adapter cable (EncorePro 710 Digital/EncorePro 720 Digital)
80354-01	Ear cushions, foam (2)
203009-01	EncorePro padded headband

S12

IN THE BOX

S12
Headset
Base
Earloops
AC power supply
Headband
User Guide
Headset stand

43297-01

43298-03

45650-03

45671-01

46186-01

46199-01

65217-01

65219-01

65388-02

SPARE PARTS

PART NO.	
43297-01	Earloop kit; S, M, L (S12)
43298-03	Headband (S12)
45650-03	Spare ring/pivot ball assembly
45671-01	AC power supply (S11/12)
46186-01	Ear cushion, leatherette
46199-01	Clothing clip (S11)
65217-01	Headset stand (S12)
65219-01	Headset (S12, no headband, ear cushions or ear hooks)
65388-02	Headset (S11)

40286-01

ACCESSORIES

40286-01	Coil cord, 10' extension, modular phone jack

VISTA M22 AUDIO PROCESSOR

Vista M22

IN THE BOX

VISTA M22

Vista M22	Phone cable
AA batteries (2)	QD to modular phone jack coil cable
Adjustment key	User Guide

26716-01

40974-01

45671-01

71173-01

71174-01

71530-01

80089-05

SPARES AND REPLACEMENT PARTS

PART NO.	
26609-03	Battery door (M22), *not shown*
26716-01	Cable, Coil, QD-to-Modular Phone Jack, Standard (M22) (Audio Processor)
40974-01	Cable, stub, modular-to-modular (audio processor-to telephone)
45671-01	AC power supply (M22)
71173-01	AP15 Cable, coil, QD-to-modular phone jack
71174-01	AP15 Cable, stub, modular-to-modular (audio processor-to telephone)
71530-01	AP15 USB power cable
80089-05	AP15 AC power supply

27019-01
27019-03

40702-01

40711-01

62976-01

ACCESSORIES

27019-01	Y-Adapter Trainer Cord, with Microphone Mute Switch and QD Clamp (EMEA part number)
27019-03	Y-adapter trainer cord, with microphone mute switch with QD cord lock
40702-01	M22 coiled cord, QD-to-modular phone jack, lightweight with QD cord lock
40710-01	Training station base (TSB): audio processor for dual headset capability, *not shown*
40711-01	Cable, 10' extension, QD-to-QD, lightweight with QD cord lock
62976-01	QD cord lock
85638-02	GE and Avaya callmaster VI adapter cables: adapts M22 to GE (model C) and Avaya callmaster VI systems, male-to-female modular connectors (2), M22 to the headset port on a Cisco deskphone, *not shown*
85638-03	GE adapter cables: adapts M22 to GE Systems (Models A and B), male-to-female modular connectors (2), *not shown*

CA22CD Single Channel

CA22CD Dual Channel

IN THE BOX

Hand held PTT unit (remote)
Base unit
Console interface cable
Battery packs (2)
AC power supply
User Guide

86658-01

217102-02

217102-03

217102-11

217102-13

218400-01

218400-02

218400-03

218400-03

218401-01

SPARES AND REPLACEMENT PARTS

PART NO.	
86658-01	USB Adapter
217102-02	Console interface cable single channel, PJ-7
217102-03	Console interface cable dual channel, PJ-7
217102-11	QD cable single channel
217102-13	QD cable dual channel
218400-01	Single channel remote, UPCS
218400-02	Single channel remote, DECT
218400-03	Dual Channel Remote, UPCS
218400-03	Dual Channel Remote, DECT
218401-01	Spare battery pack

MDA220USB/MDA500 QD SERIES

MDA220 USB

IN THE BOX

MDA220 USB Multi-Device adapter
Telephone interface cable
Quick Start Guide

MDA500 QD Series

IN THE BOX

MDA500 audio processor
4 or 6-Pin QD cable accessory
PC cable USB-A to C or USB-C to A
Telephone interface cable

86007-01

80287-01

86008-01

86079-01

37818-11

37820-11

38439-11

38633-11

38734-11

60961-35

78887-01

87317-01

87327-01

202578-01

211076-01

212539-01

SPARES AND REPLACEMENT PARTS

PART NO.	
86007-01	Telephone interface cable

ACCESSORIES

74403-01	USB extension cable, *not shown*
80287-01	On-Line indicator, straight plug
86008-01	Bundle, HL10/AC power supply bundle (universal)
86079-01	AC power supply, straight plug (universal)
209505-01	USB-A to USB-C adapter, *image on page 33*
209506-01	USB-C to USB-A adapter, *image on page 33*

CABLES AND CONNECTORS FOR REMOTE DESK PHONE CALL CONTROL

37818-11	APS-11, Electronic Hook Switch, Siemens®/Funwerk®/Auerswald®/ Agfeo®/Aastra®/DeTeWe®
37820-11	APT-31, Electronic Hook Switch, Avaya® GmbH (Tenovis)
38350-13	APC-43, Electronic Hook Switch, Cisco®, *not shown*
38439-11	APP-51, Electronic Hook Switch, Poly
38633-11	APV-66, Electronic Hook Switch, Avaya (EU24)
38734-11	APV-63, Electronic Hook Switch, Avaya
60961-35	HL10 handset lifter, Straight Plug
78887-01	RD-1 Electronic Hook Switch, Shoretel®/Toshiba®/ Adtran®/Allworx® (not available in Europe)
85638-01	EHS Extension Cable, Cisco, *not shown*
87317-01	APC-45, Electronic Hook Switch, Cisco
87327-01	APD-80, Electronic Hook Switch
89280-11	APN-91, Electronic Hook Switch, NEC®, *image on page 8*
201081-01	APC-82, Electronic Hook Switch, Cisco, *image on page 8*
202578-01	APU-72, Electronic Hook Switch, Avaya (Nortel®)/Cisco
211076-01	APU-76 EHS Cable
212539-01	APA-24 Alcatel EHS Cable

DA75

DA85

DA90

IN THE BOX

DA75/DA85/DA90

DA series audio processor

User Guide

38733-01

38733-03

62976-01

ACCESSORIES

PART NO.	
38733-01	6-4 Pin adapter
38733-03	4-6 Pin adapter with lock (DA90)
62976-01	QD cord lock

CABLES AND CONNECTORS

18709-01

26716-01

27019-01
27019-03

27708-01

28959-01

40702-01

40703-01

40711-01

40974-01

45588-01

49323-46

62976-01

66268-03

72442-41

PART NO.	
18709-01	Modular-to-Plug-Prong adapter (PJ327)
26716-01	Cable, coil, QD-to-modular phone jack (audio processor)
27019-01	Y-Adapter Trainer Cord, with Microphone Mute Switch and QD Clamp (EMEA part number)
27019-03	Y-Adapter trainer cord with microphone mute switch and QD clamp
27708-01	Mute switch, QD in-line (standard)
28959-01	Cable, QD to two 3.5 mm plugs
40702-01	Coiled cord, QD-to-modular phone jack, lightweight (audio processor)
40703-01	Cable, 10' extension, QD-to-QD, standard weight
40711-01	Cable, 10' extension, QD-to-QD, lightweight
40974-01	Cable, stub, modular-to-modular (audio processor-to-telephone)
45588-01	Modlocs: tethers headset to telephone, headset to audio processor, or audio processor to phone (25 per bag)
49323-46	HIC-10 adapter cable
62976-01	QD cord lock
66268-03	A10 direct connect cable

AVAYA PHONE CABLES

72442-41	HIS adapter cable (check compatibility with your Avaya phone)

209506-01

209505-01

217877-01

217878-01

Bluetooth USB Adapters

205250-01

211002-01

DECT USB Adapters

PART NO.	
204880-01	BT600 USB adapter, in a bag, *not shown*
205250-01	BT600 USB adapter, boxed
209505-01	USB-A to USB-C adapter
209506-01	USB-C to USB-A adapter
211002-01	BT600 USB-C, in a bag
211249-01	BT600 USB-C, boxed
217877-01	BT700 USB adapter
217878-01	BT700 USB-C, boxed

209850-04

D200 SPARES

209200-01	D200 USB-A, Savi, adapter, DECT 6.0, NA, *not shown*
209200-02	D200 USB-A, Savi, adapter, DECT, UK/EURO/AUS/NZ, *not shown*
209200-03	D200 USB-A, Savi, adapter, MOC, DECT 6.0, NA, *not shown*
209200-04	D200 USB-A, Savi, adapter, MOC, DECT, UK/EURO/AUS/NZ, *not shown*
209850-01	D200 USB-C, Savi, adapter, DECT 6.0, NA, *not shown*
209850-02	D200 USB-C, Savi, adapter, DECT, UK/EURO/AUS/NZ, *not shown*
209850-03	D200 USB-C, Savi, adapter, MOC, DECT 6.0, NA, *not shown*
209850-04	D200 USB-C, Savi, Adapter, MOC, DECT, UK/EURO/AUS/NZ

BLACKWIRE 200 SERIES

Blackwire 210

Blackwire 215

Blackwire 220

Blackwire 225

IN THE BOX (BULK PACK, 45 HEADSETS)

BLACKWIRE 210
Headset
User Guide

BLACKWIRE 215
Headset
User Guide

BLACKWIRE 220
Headset
User Guide

BLACKWIRE 225
Headset
Carrying case
User Guide

88225-01

SPARES AND REPLACEMENT PARTS

PART NO.	
88225-01	Ear cushions, foam (2) (Blackwire 215/Blackwire 225)

24460-01

83421-02

85298-01

85697-01

89862-01

200070-01

205295-01

ACCESSORIES

24460-01	Clothing clip
83421-02	Ear cushions, leatherette (Blackwire 215/Blackwire 225)
85298-01	Blackwire travel case
85697-01	Clothing clip
89862-01	Ear cushions, leatherette (2) (Blackwire 315/Blackwire 325)
200070-01	Blackwire soft carrying case
205295-01	3.5 mm splitter

BLACKWIRE 300 SERIES

Blackwire 310

Blackwire 315

Blackwire 320

Blackwire 325

IN THE BOX (BULK PACK, 45 HEADSETS)

BLACKWIRE 310
Headset
User Guide

BLACKWIRE 315
Headset
Carrying case
User Guide

BLACKWIRE 320
Headset
User Guide

BLACKWIRE 325
Headset
Carrying case
User Guide

85697-01

88225-01

89862-01

SPARES AND REPLACEMENT PARTS

PART NO.	
85697-01	Clothing clip
88225-01	Ear cushions, foam (2) (Blackwire 310/Blackwire 320)
89862-01	Ear cushions, leatherette (2) (Blackwire 315/Blackwire 325)

BLACKWIRE 420

Blackwire 420

IN THE BOX

BLACKWIRE 420
Headset
Quick Start Guide
Carrying pouch

83296-02

SPARES AND REPLACEMENT PARTS

PART NO.	
83296-02	Travel pouch, neoprene

BLACKWIRE 435

Blackwire 435

IN THE BOX

BLACKWIRE 435

Headset
Clothing clip
Carrying case
Quick Start Guide

85692-01

85695-01

85696-01

85697-01

85693-01

85694-01

SPARES AND REPLACEMENT PARTS

PART NO.	
85692-01	Ear loop and ear gel kit
85695-01	Blackwire 435 Carrying case, *headset not included*
85696-01	Replacement Ear bud with Y connector
85697-01	Clothing clip

ACCESSORIES

85693-01	Neckband and 2 links
85694-01	Neckband, 2 links and carry case

BLACKWIRE 500 SERIES

Blackwire 510

Blackwire 520

IN THE BOX

BLACKWIRE 510

Headset
Quick Start Guide
Carrying case

BLACKWIRE 520

Headset
Quick Start Guide
Carrying case

200070-01

SPARES AND REPLACEMENT PARTS

PART NO.	
200070-01	Blackwire soft carrying case

89109-01

ACCESSORIES

89109-01	Blackwire hard carrying case

BLACKWIRE 600 SERIES

Blackwire 610

Blackwire 620

IN THE BOX

BLACKWIRE 610
Headset
Carrying pouch
Ear cushion, foam
Quick Start Guide
Clothing clip

BLACKWIRE 620
Headset
Carrying pouch
Ear cushions, foam
Quick Start Guide
Clothing clip

24460-01

60425-01

85298-01

SPARES AND REPLACEMENT PARTS

PART NO.	
24460-01	Clothing clip
40709-01	Ear cushions, foam (2) (Blackwire 610/Blackwire 620), *image on page 45*
60425-01	Ear cushions, leatherette (2) (Blackwire 610/Blackwire 620)

ACCESSORIES

85298-01	Blackwire travel case

BLACKWIRE 700 SERIES

Blackwire 710

Blackwire 720

Blackwire 725

IN THE BOX

BLACKWIRE 710
Headset
Carrying case
QD USB cable
Quick Start Guide

BLACKWIRE 720
Headset
Carrying case
QD USB cable
Quick Start Guide

BLACKWIRE 725
Headset
Carrying case
Quick Start Guide

89109-01

89862-01

200070-01

SPARES AND REPLACEMENT PARTS

PART NO.	
89109-01	Blackwire Hard carrying case (C710/720)
89862-01	Ear cushions, foam (2) (Blackwire 710/Blackwire 720/Blackwire 725)
200070-01	Blackwire soft carrying case (C725)

BLACKWIRE 7225

Blackwire 7225, sand

Blackwire 7225, espresso

IN THE BOX

Headset
Carrying case
Quick Start Guide

212295-01

212295-02

SPARES AND REPLACEMENT PARTS

PART NO.	
212295-01	Spare, Ear cushion, leatherette, Blackwire 7225, espresso
212295-02	Spare, Ear cushion, leatherette, Blackwire 7225, sand
213440-01	Spare, Carrying case, Blackwire 7225, *not shown*

CALISTO 420

Calisto 420

IN THE BOX

Speakerphone
Carrying case
USB cable

Calisto 620

Calisto 610

IN THE BOX

CALISTO 620
Speakerphone
USB adapter
Carrying case
USB AC adapter
USB to micro USB cable

CALISTO 610
Speakerphone
Carrying case

89305-01

89258-01

89034-02

89269-01

89259-01

89259-02

SPARES

PART NO.	
89305-01	Battery (P620)
89258-01	Carrying case
89034-02	USB AC adapter (P620)
89269-01	USB to micro USB cable
89259-01	BT300-M Bluetooth USB adapter
89259-02	BT300 Bluetooth USB adapter
204880-01	BT600 USB adapter, in a bag, *not shown*

205250-01

201263-01

ACCESSORIES

205250-01	BT600 Bluetooth USB adapter (P620)
201263-01	Security tab (P620)
204880-01	BT600 USB adapter, in a bag, *not shown*

CALISTO 800 SERIES

Calisto 825

Calisto 835

IN THE BOX

CALISTO 825
Speakerphone
USB cable
Wireless mic and charging dock
Quick Start Guide

CALISTO 835
Speakerphone
Landline Telephone cable
Wireless mic and charging dock
USB cable
AC power supply
Quick Start Guide

84104-01

SPARES AND REPLACEMENT PARTS

PART NO.	
84104-01	AC power supply, straight plug (P835)

28959-01

84101-01

84104-01

ACCESSORIES

28959-01	Cable, QD to two 3.5 mm plugs (H-Series headsets)
84101-01	Carrying case
84104-01	AC power supply, straight plug (P825)

CALISTO 820/830

Calisto 820

Calisto 830

IN THE BOX

CALISTO 820
Speakerphone
Quick Start Guide
USB cable

CALISTO 830
Speakerphone
USB cable
AC power supply
Quick Start Guide
Landline telephone cable

CALISTO 5200

Calisto 5200

IN THE BOX

CALISTO 5200
Carrying case
Quick Start Guide
Compliance insert
Warranty card
Safety Guide

CALISTO 5300

Calisto 5300

IN THE BOX

CALISTO 5300
Carrying case
Quick Start Guide
Compliance insert
Warranty card
Safety Guide

216827-01

216827-02

ACCESSORIES

PART NO.	
204880-01	BT600 USB adapter, boxed (EMEA part number), *image on page 9*
205250-01	BT600 USB adapter, boxed, *image on page 9*
211035-01	Carrying bag, Calisto 3200 and Calisto 5200
211249-01	BT600 USB-C adapter, *image on page 9*
216827-01	Spare pouch USB-A (Calisto 5300)
216827-02	Spare pouch USB-C (Calisto 5300)

CALISTO 7200

Calisto 7200

IN THE BOX

Speakerphone
USB cable with locking mechanism
Personal USB cable
Carry case
Quick Start Guide

213754-01

213810-01

SPARES

PART NO.	
211737-01	Spare, 4 ft USB cable Calisto P7200 (non security), *not shown*
213754-01	Spare soft carry case, Calisto 7200
213810-01	Spare, 10 ft Security cable, Calisto P7200

CA12CD-S

CA12CD-S

IN THE BOX

Hand held PTT unit (remote)
Base unit
Console interface cable
Battery packs (2)
AC power supply
User Guide

68331-01

80090-05

80322-01

92697-01

201059-01

SPARES AND REPLACEMENT PARTS

PART NO.	
68331-01	Console interface cable
80090-05	AC power supply
80322-01	Battery pack for remote
92697-01	Remote cable
201059-01	Remote PTT unit

CS55/CS50/CS50-USB

CS55

CS50

CS50-USB

IN THE BOX

CS55/CS50/CS50-USB

Headset
Cushions for headset ring (3)
Earloops (4)
Uniband headband with leatherette cushion
AC power supply
Dual filter cable (CS50)
Quick Start Guide
PerSonoCall® Software (CS50-USB)
Base

65700-01

66735-01

80090-05

SPARES AND REPLACEMENT PARTS

PART NO.	
65700-01	Ear cushions for headset ring (3)
66735-01	Uniband headband
80090-05	AC power supply

46429-01

65116-02

ACCESSORIES

46429-01	On-Line indicator extension cord
65116-02	On-Line indicator light

NOTE: For Cables and Connectors for Remote Desk Phone Call Control (does not apply to CS50-USB), see page 8.

CS70N

IN THE BOX

Headset and eartips
Telephone interface cable
Base
Quick Start Guide
AC power supply

DISCONTINUED MODELS

CS70

72913-01

80090-05

SPARES AND REPLACEMENT PARTS

PART NO.	
72913-01	Eartips (5, 3 with gel tips)
80090-05	AC power supply

46429-01

65116-02

ACCESSORIES

46429-01	On-Line indicator extension cord
65116-02	On-Line indicator light

60961-32

87317-01

87327-01

CABLES AND CONNECTORS FOR REMOTE DESK PHONE CALL CONTROL

60961-32	HL10 handset lifter, right angle plug
87317-01	APC-45, Electronic Hook Switch, Cisco
87327-01	APD-80, Electronic Hook Swtich

CS500 SERIES

CS530

CS520

CS510

IN THE BOX

CS530
Headset and eartips
Telephone interface cable
Base
Quick Start Guide
AC power supply

CS520
Headset and battery
Telephone interface cable
Base
Quick Start Guide
AC power supply

CS510
Headset and battery
Telephone interface cable
Base
Quick Start Guide
AC power supply

71782-01

72742-02

72913-01

86919-01

86920-01

87235-01

202599-03

71781-01

SPARES AND REPLACEMENT PARTS

PART NO.	
71782-01	Ear cushions, leatherette (2) (CS510/CS520)
72742-02	Headband support (CS510/CS520)
72913-01	Eartips: 5, 3 with gel tips (CS530)
86919-01	Headset (CS510)
86920-01	Headset (CS520)
87235-01	Headset (CS530)
202599-03	Battery with removal tool (CS510/CS520)
71781-01	Ear cushions, foam (2) (CS510/CS520)

83769-11

83776-11

HEADSET CHARGING ACCESSORIES FOR MULTI-SHIFT ENVIRONMENTS

83769-11	Over-the-ear charging cradle (CS530)
83776-11	Over-the-head charging cradle (CS510/CS520)

27190-01

43298-03

43937-01

46186-01

IN THE BOX

PART NO.	
27190-01	Cable, coil, QD-to-modular phone jack
43298-03	Headband
43937-01	Ear cushions, foam (2) (CT12)
45651-01	Ear loop, conformable, *not shown*
46186-01	Ear cushion, leatherette (CT12)

DA SERIES AUDIO PROCESSORS

DA40

DA45

DA55

DA60

DA70

DA80

IN THE BOX

DA40/DA45/DA55/DA60/DA70/DA80
DA Series Audio Processor
User Guide

65581-01

65582-01

SPARES AND REPLACEMENT PARTS

PART NO.	
65581-01	In-line volume and mute (DA60)
65582-01	Cable, QD to modular phone jack, no in-line control (DA55)

27708-01

ACCESSORIES

27708-01	Mute switch, QD in-line (DA40)

ENCOREPRO 535

EncorePro 535 USB

IN THE BOX

ENCOREPRO 535 USB
Headset
User Guide

ENTERA USB

Entera HW111N-USB

Entera HW121N-USB

IN THE BOX

ENTERA HW111N-USB
Headset
Carrying pouch
Ear cushion, foam
Quick Start Guide
Clothing clip

ENTERA HW121N-USB
Headset
Carrying pouch
Ear cushion, foam
Quick Start Guide
Clothing clip

24460-01

40709-01

60425-01

SPARES AND REPLACEMENT PARTS

PART NO.	
24460-01	Clothing clip
40709-01	Ear cushions, foam (2)
60425-01	Ear cushions, leatherette (2)

MDA100 QD SERIES

MDA100 QD

MDA105 QD

IN THE BOX

MDA100 QD
Switch
QD coil cable
RJ9 phone cable
USB to micro USB cable

IN THE BOX

MDA105 QD
Switch
QD coil cable
RJ9 phone cable
USB to micro USB cable

26716-01

207966-01

207967-01

208418-01

SPARES AND REPLACEMENT PARTS

PART NO.	
26716-01	QD coil cable
207966-01	RJ9 phone cable
207967-01	USB to micro USB cable
208418-01	Volume control

MDA400 QD SERIES

MDA480 QD

MDA490 QD

IN THE BOX

MDA480 QD
Audio processor
DA80
In-line controller
Telephone interface cable

MDA490 QD
Audio processor
DA90
In-line controller
Telephone interface cable

MX10 AUDIO PROCESSOR

MX10

IN THE BOX

Audio processor
QD to modular phone jack coil cable
Phone cable
Adjustment key
Computer cord
User Guide
AC power supply

26716-01

40974-01

44877-02

84104-01

SPARES AND REPLACEMENT PARTS

PART NO.	
26716-01	Cable, coil, QD-to-modular phone jack (audio processor)
40974-01	Cable, stub, modular-to-modular (audio processor-to-telephone)
43590-01	Battery and compatibility doors, *not shown*
44877-02	Computer cord, MX10 to sound card
84104-01	AC power supply

27019-01
27019-03

62976-01

ACCESSORIES

27019-01	Y-Adapter Trainer Cord, with Microphone Mute Switch and QD Clamp (EMEA part number)
27019-03	Y-Adapter trainer cord with microphone mute switch and QD clamp
62976-01	QD cord lock

S11

S11

IN THE BOX

S11
Headset
AC power supply
Headset stand
User Guide
Base

Savi 445

Savi 440

Savi 430

Savi 420

Savi 410

IN THE BOX

SAVI 445

Headset and battery	Deluxe charging cradle	DECT™ 6.0 USB adapter
Over-the-head headband	Charging base	Carrying case
Behind-the-head neckband	AC power supply	Spare battery
Headset fit kit	USB charging cable	Quick Start Guide

SAVI 440

Headset and battery	Charging cradle	DECT™ 6.0 USB adapter
Over-the-head headband	Charging base	Carrying case
Behind-the-head neckband	AC power supply	Quick Start Guide
Headset fit kit	USB charging cable	

SAVI 430

Headset and eartips	AC power supply	Carrying case
Charging cradle	USB charging cable	Quick Start Guide
Charging base	DECT 6.0 USB adapter	

SAVI 420

Headset	AC power supply	Carrying case
Charging cradle	Charging base	Quick Start Guide
DECT 6.0 USB adapter	Base stabilizer	

SAVI 410

Headset	AC power supply	Carrying case
Charging cradle	Charging base	Quick Start Guide
DECT 6.0 USB adapter	Base stabilizer	

69519-01

87236-01

72913-01

81423-01

82905-21

83322-11

83323-11

83356-01

83550-01

83769-11

83776-11

83876-01

SPARES AND REPLACEMENT PARTS

PART NO.	
69519-01	USB charging cable, non-magnetic/SMIF charging* (W430)
87236-01	USB charging cable, magnetic charging (W430)
72913-01	Eartips: 5, 3 with gel tips (W430)
81423-01	AC power supply, straight plug
82905-21	Headset with eartips and charge cradle (W430)
83322-11	Headset and charge cradle (W420)
83323-11	Headset and charge cradle (W410)
83356-01	Headset and charge cradle, fit kit (W440)
83550-01	D100™ DECT 6.0 USB adapter (with charge base, USB cable and AC power supply)
83769-11	Base charging cradle** (W430)
83776-11	Over-the-head charging cradle (W410/W420)
83876-01	D100 DECT 6.0 USB adapter with charge base, USB cable and AC power supply (Microsoft® version)
202599-03	Battery (W410/W420), *not shown*

**Newer W430 headsets feature magnetic docking. See image for reference.*

***Includes cradles for old and new W430 headsets (non-magnetic/SMIF and magnetic)*

SAVI 400 SERIES CONTINUED

84599-01

84600-01

84604-01

84605-01

84606-01

86005-01

86006-01

87229-01

89109-01

204755-01

SPARES AND REPLACEMENT PARTS (CONTINUED)

PART NO.	
84599-01	Standard charging cradle (W440)
84600-01	Deluxe charging cradle (W445)
84604-01	Savi fit kit, earloops/earbuds/foam cushions (W440)
84605-01	Headband (W440)
84606-01	Neckband (W440)
86005-01	Charge base, 1 unit, 3 pins (with AC power supply)
86006-01	Hard carrying case (W430/W440)
87229-01	Leatherette ear cushions, 2 units (W440)
89109-01	Headset carrying case (W410/W420)
204755-01	Savi spare battery with on/off switch (W440/W445)

84600-01

84601-01

84602-01

84603-01

87527-01

88940-01

88941-01

ACCESSORIES

84600-01	Deluxe charging cradle (W440)
84601-01	Deluxe charging cradle kit (W440) (deluxe charging cradle + spare battery)
84602-01	USB deluxe charger (W440)
84603-01	USB deluxe charging kit (W440) (Deluxe charger + spare battery)
87527-01	Foam ear loop covers, 20 units (W440)
88940-01	Spare eartips, 25 units, small (W440)
88941-01	Spare eartips, 25 units, medium (W440)

Savi 745

Savi 740

Savi 730

Savi 720

Savi 710

IN THE BOX

SAVI 745

Headset and battery	Base
Headband	AC power supply
Neckband	Telephone interface cable
Headset fit kit	USB cable
Deluxe charging cradle	Quick Start Guide
Spare battery	

SAVI 740

Headset and battery	Base
Headband	AC power supply
Neckband	Telephone interface cable
Headset fit kit	USB cable
Charging cradle	Quick Start Guide

SAVI 730

Headset and eartips	AC power supply	Quick Start Guide
Charging cradle	Telephone interface cable	
Base	USB cable	

SAVI 720

Headset	AC power supply	Quick Start Guide
Charging cradle	Telephone interface cable	
Base	USB cable	

SAVI 710

Headset	AC power supply	Quick Start Guide
Charging cradle	Telephone interface cable	
Base	USB cable	

71782-01

72742-02

72913-01

81423-01

82905-21

83322-11

83323-11

83356-01

83769-11

83776-11

84598-01

84599-01

SPARES AND REPLACEMENT PARTS

PART NO.	
71782-01	Ear cushions, leatherette (2) (W710/W720)
72742-02	Headband support (W710/W720)
72913-01	Eartips: 5, 3 with gel tips (W730)
81423-01	AC power supply, straight plug
82905-21	Headset and charge cradle (W730)
83322-11	Headset and charge cradle (W720)
83323-11	Headset and charge cradle (W710)
83356-01	Headset and charge cradle (W740)
83769-11	Charging cradle* (W730)
83776-11	Over-the-head charging cradle (W710/W720)
84598-01	Savi spare battery (W740/W745)
84599-01	Standard charging cradle (W740)
202599-03	Battery with removal tool (W710/W720), *not shown*

**Includes cradles for old and new W730 headsets (non-magnetic/SMIF and magnetic)*

84600-01

84604-01

84605-01

84606-01

87229-01

SPARES AND REPLACEMENT PARTS (CONTINUED)

PART NO.	
84600-01	Deluxe Charging cradle (W745)
84604-01	Savi Fit kit, earloops/earbuds/foam cushions (W740/W745)
84605-01	Headband (W740/W745)
84606-01	Neckband (W740/W745)
86007-01	Telephone interface cable, *image on page 52*
86658-01	USB cable, *image on page 52*
87229-01	Leatherette ear cushions, 2 units (W740/W745)

71781-01

80287-01

84601-01

84602-01

84603-01

84609-01

86005-01

204755-01

37818-11

ACCESSORIES

71781-01	Ear cushions, foam (2) (W710/W720)
80287-01	On-Line indicator, straight plug
82905-21	Headset and charge cradle (W730), *image on page 46*
83322-11	Headset and charge cradle (W720), *image on page 46*
83323-11	Headset and charge cradle (W710), *image on page 46*
83356-01	Headset and charge cradle (W740), *image on page 46*
84601-01	Deluxe Charging cradle kit (W740) (includes Deluxe Charging cradle + spare battery)
84602-01	USB deluxe charger (W745)
84603-01	USB deluxe charging kit (W740) (deluxe charger + spare battery)
84609-01	Charge base, 5 units, 3 pins (with AC power supply)
86005-01	Charge base, 1 unit, 3 pins (with AC power supply)
87527-01	Foam ear loop covers, 20 units (W740/W745), *image on page 47*
88940-01	Spare eartips, 25 units, small (W740/W745), *image on page 47*
88941-01	Spare eartips, 25 units, medium (W740/W745), *image on page 47*
204755-01	Savi spare battery with on/off switch (W740/W745)

37820-11

38350-13

38439-11

38633-11

38734-11

60961-35

78887-01

211076-01

212539-01

CABLES AND CONNECTORS FOR REMOTE DESK PHONE CALL CONTROL

37818-11	APS-11, Electronic Hook Switch, Siemens®/Funwerk®/Auerswald®/Agfeo®/Aastra®/DeTeWe®
37820-11	APT-31, Electronic Hook Switch, Avaya® GmbH (Tenovis)
38350-13	APC-43, Electronic Hook Switch, Cisco
38439-11	APP-51, Electronic Hook Switch, Poly
38633-11	APV-66, Electronic Hook Switch, Avaya (EU24)
38734-11	APV-63, Electronic Hook Switch, Avaya
60961-35	HL10™ Handset Lifter, Straight Plug
78887-01	RD-1 Electronic Hook Switch, Shoretel®/Toshiba®/Adtran®/Allworx® (not available in Europe)
85638-01	EHS Extension Cable, Cisco, *not shown*
87317-01	APC-45, Electronic Hook Switch, *image on page 58*
87327-01	APD-80, Electronic Hook Switch, *image on page 58*
89280-11	APN-91, Electronic Hook Switch, NEC®, *image on page 58*
201081-01	APC-82, Electronic Hook Switch, Cisco, *image on page 58*
202578-01	APU-72, Electronic Hook Switch, Avaya (Nortel®)/Cisco, *image on page 58*
211076-01	APU-76 EHS Cable
212539-01	APA-24 Alcatel EHS Cable

Savi Go

IN THE BOX

SAVI GO

Headset and earloop
USB charging cable
Headband
Bluetooth USB adapter
Ear tab and cushion
Quick Start Guide
Charging base
Plantronics software installer CD
AC power supply

81423-01

81424-01

81426-01

86005-01

SPARES AND REPLACEMENT PARTS

PART NO.	
81423-01	AC power supply, straight plug
81424-01	Headband (WG100)
81426-01	Comfort kit, eartips/ear cushions (2) (WG100)
86005-01	Charge base, 1 unit, 3 pins (with AC power supply)

SAVI OFFICE

Savi Office, W0100/101

Savi Office, W0200/201

Savi Office, W0350

Savi Office, W0300

IN THE BOX

SAVI OFFICE W0100/101

Headset	Base
Headband	AC power supply
Ear Tab and Cushion	Telephone interface cable
Earloop	USB cable
Charging cradle	Quick Start Guide

SAVI OFFICE W0200/201

Headset and eartips	Telephone interface cable
Charging cradle	USB cable
Base	Quick Start Guide
AC power supply	

SAVI OFFICE W0350

Headset	Telephone interface cable
Charging cradle	USB cable
Base	Quick Start Guide
AC power supply	

SAVI OFFICE W0300

Headset	Telephone interface cable
Charging cradle	USB cable
Base	Quick Start Guide
AC power supply	

64399-03

71782-01

72742-02

72913-01

81423-01

81424-01

81426-01

82905-21

SPARES AND REPLACEMENT PARTS

PART NO.	
64399-03	Headset battery (w/removal tool) (W0300/W0350)
71782-01	Ear cushions, leatherette (2) (W0300/W0350)
72742-02	Headband support (W0300/W0350)
72913-01	Eartips: 5, 3 with gel tips (W0200/201)
81423-01	AC power supply, straight plug
81424-01	Convertible headband (W0100/101)
81426-01	Convertible comfort kit, eartips/ear cushions, 2 (W0100/101)
82905-21	Headset and Charging cradle (W0200/201)

83769-11

86007-01

86658-01

SPARES AND REPLACEMENT PARTS (CONTINUED)

PART NO.	
83769-11	Over-the-ear Charging cradle (W0200/201)
86007-01	Telephone interface cable
86658-01	USB cable

71781-01

80287-01

84609-01

86005-01

ACCESSORIES

71781-01	Ear cushions, foam (2) (W0300/W0350)
80287-01	On-Line indicator, straight plug
84609-01	Charge base, 5 unit, 3 pins (with AC power supply)
86005-01	Charge base, 1 unit, 3 pins (with AC power supply)

37818-11

37820-11

38350-13

38439-11

38633-11

38734-11

60961-35

89280-11

212539-01

CABLES AND CONNECTORS FOR REMOTE DESK PHONE CALL CONTROL

37818-11	APS-11, Electronic Hook Switch, Siemens®/Funwerk®/Auerswald®/ Agfeo®/Aastra®/DeTeWe®
37820-11	APT-31, Electronic Hook Switch, Avaya® GmbH (Tenovis)
38350-13	APC-43, Electronic Hook Switch, Cisco®
38439-11	APP-51, Electronic Hook Switch, Poly
38633-11	APV-66, Electronic Hook Switch, Avaya (EU24)
38734-11	APV-63, Electronic Hook Switch, Avaya
60961-35	HL10 handset lifter, Straight Plug
78887-01	RD-1 Electronic Hook Switch, Shoretel®/Toshiba®/ Adtran®/Allworx® (not available in Europe), *image on page 6*
87317-01	APC-45, Electronic Hook Switch, Cisco, *image on page 6*
87327-01	APD-80, Electronic Hook Swtich, *image on page 6*
89280-11	APN-91, Electronic Hook Switch, NEC
202578-01	APU-72, Electronic Hook Switch, Avaya (Nortel®)/Cisco, *image on page 6*
212539-01	APA-24, Electronic Hook Switch, Alcatel®

SUPRA

IN THE BOX

SUPRA

PART NO.	
10757-00	Background noise suppressor (H51/H61)
15729-05	Ear cushions, foam (2)
17593-01	Voice tube, clear (H51/H61)
24316-01	Windscreen (H51N/H61N)
60425-01	Ear cushions, leatherette (2)
61871-01	Ear cushions, super soft, foam (2)

SUPRAPLUS SL (NOT SHOWN)

IN THE BOX

SUPRAPLUS SL

PART NO.	
10757-00	Background noise suppressor (H351/H361)
24460-01	Clothing clip
29960-01	Voice tube, clear (H351/H361)
40709-02	Ear cushions, foam (2)
65932-01	Value pack for voice tube models (H351/H361)
67712-01	Ear cushions, leatherette (2)
83195-01	Ear Cushion, circumaural

Supraplus wideband HW251, Voice Tube

Supraplus wideband HW251N, Noise-canceling

Supraplus wideband HW261, Voice Tube

Supraplus wideband HW261N, Noise-canceling

IN THE BOX

HW251
Headset
User Guide

HW251N
Headset
User Guide

HW261
Headset
User Guide

HW261N
Headset
User Guide

24460-01

29960-01

40709-02

SPARES AND REPLACEMENT PARTS

PART NO.	
24460-01	Clothing clip
29960-01	Voice tube, clear (HW251/HW261)
40709-02	Ear cushions, foam (2) (SupraPlus wideband)

10757-00

26716-01

27019-01
27019-03

27708-01

40711-01

62976-01

66268-03

67712-01

ACCESSORIES

10757-00	Background noise suppressor (HW251/HW261)
26716-01	Cable, coil, QD-to-modular phone jack (audio processor)
27019-01	Y-Adapter Trainer Cord, with Microphone Mute Switch and QD Clamp (EMEA part number)
27019-03	Y-Adapter trainer cord, with microphone mute switch and QD clamp
27708-01	Mute switch, QD in-line
29960-01	Voice tube, clear (HW251/HW261), *not shown*
40711-01	Cable, 10' Extension, QD-to-QD, Lightweight
62976-01	QD cord lock
65932-01	Value pack for voice tube models (HW251/HW261) (ear cushions, voice tube, background noise suppressor, QD cord clip), *not shown*
66268-03	A10 Direct connect cable
67712-01	Ear cushions, leatherette (2) (SupraPlus Wideband)
83195-01	Ear cushion, circumaural (SupraPlus Wideband), *not shown*

SUPRAPLUS WIRELESS

Supraplus Wireless CS351N

Supraplus Wireless CS361N

IN THE BOX

SUPRAPLUS WIRELESS

Headset
Foam and leatherette ear cushions
Base
AC power supply
Phone cable
Quick Start Guide

DISCONTINUED MODELS

CS351, CS361

64399-03

71781-01

71782-01

80090-05

SPARES AND REPLACEMENT PARTS

PART NO.	
64399-03	Headset battery (w/removal tool)
71781-01	Ear cushions, foam (2) (CS351N, CS361N)
71782-01	Ear cushions, leatherette (2) (CS351N, CS361N)
80090-05	AC power supply

46429-01

65116-02

ACCESSORIES

46429-01	On-Line indicator extension cord
65116-02	On-Line indicator light

NOTE: For Cables and Connectors for Remote Desk Phone Call Control, see page 8.

VISTAPLUS AP15 AUDIO PROCESSOR

VistaPlus® AP15

IN THE BOX

VISTAPLUS AP15

VistaPlus AP15	Phone cable
AC power supply	QD to modular phone jack coil cable
USB power cable	User Guide

VOYAGER 510/VOYAGER 510-USB

46429-01

60961-32

65116-02

72913-01

IN THE BOX

VOYAGER 510/VOYAGER 510-USB

PART NO.	
46429-01	On-Line indicator extension cord
60961-32	HL10 handset lifter (510S)
65116-02	On-Line indicator light (510S)
72913-01	Eartips (5, 3 with gel tips)

VOYAGER 3200 UC

Voyager 3200 UC

IN THE BOX

VOYAGER 3200 UC

Headset
Product card
USB charge cable
Safety booklet
BT600 USB adapter
Warranty card
Charging case
Eartip kit (small, large, and ear loop)

201955-01

201955-02

201955-03

201885-01

205250-01

211249-01
211002-01

SPARES AND REPLACEMENT PARTS

PART NO.	
201955-01	Ear gel, small (qty 3), with earloop
201955-02	Ear gel, medium (qty 3), with earloop
201955-03	Ear gel, large (qty 3), with earloop
201885-01	Spare, cable assembly, std-a plug to micro USB B, 660 mm, black
204880-01	BT600 USB adapter, in a bag, *not shown*
205250-01	BT600 USB adapter, boxed
211249-01	BT600 USB-C, boxed
211002-01	BT600 USB-C, in a bag

89034-01

89110-01

207363-01

ACCESSORIES

89034-01	AC charger (NA only)
89110-01	USB car charger
207363-01	Charging case

VOYAGER EDGE UC

Voyager Edge Charge Case

Voyager Edge UC

IN THE BOX

VOYAGER EDGE UC

Headset
Earloop
Mini Bluetooth® USB adapter
S/M/L eartips
USB charging case
Modular AC wall charger
USB to micro USB cable (see Calisto 610)
Bluetooth dongle

85117-01

85117-02

89034-01

201885-01

201885-02

201955-01

201955-02

201955-03

SPARES AND REPLACEMENT PARTS

PART NO.	
85117-01	BT300-M mini Bluetooth USB adapter
85117-02	BT300 mini Bluetooth USB adapter
89034-01	Modular AC wall charger
201885-01	USB to Micro USB charging cable
201885-02	USB to Micro USB charging cable, white
201955-01	Small, eartip x 3 and earloop
201955-02	Medium, eartip x 3 and earloop
201955-03	Large, eartip x 3 and earloop
203790-01	Charge case, *not shown*

89110-01

ACCESSORIES

89110-01	USB car charger

Voyager Legend CS

IN THE BOX

VOYAGER LEGEND CS

Headset
Power supply
Base
Eartips
Telephone interface cable
USB charge cable

89032-01

89037-01

89037-02

37818-11

37820-11

38350-13

38439-11

38633-11

38734-11

60961-35

78887-01

87317-01

87327-01

89280-11

201081-01

202578-01

211076-01

212539-01

SPARES AND REPLACEMENT PARTS

PART NO.	
89032-01	USB charging cable (9")
89037-01	Small, 3-Pack, eartips/foam eartip covers
89037-02	Medium, 3-Pack, eartips/foam eartip covers

CABLES AND CONNECTORS FOR REMOTE DESK PHONE CALL CONTROL

37818-11	APS-11, Electronic Hook Switch, Siemens®/Funwerk®/Auerswald®/ Agfeo®/Aastra®/DeTeWe®
37820-11	APT-31, Electronic Hook Switch, Avaya® GmbH (Tenovis)
38350-13	APC-43, Electronic Hook Switch, Cisco
38439-11	APP-51, Electronic Hook Switch, Poly
38633-11	APV-66, Electronic Hook Switch, Avaya (EU24)
38734-11	APV-63, Electronic Hook Switch, Avaya
60961-35	HL10 handset lifter, Straight Plug
78887-01	RD-1 Electronic Hook Switch, Shoretel®/Toshiba®/ Adtran®/Allworx® (not available in Europe)
85638-01	EHS Extension Cable, Cisco, *not shown*
87317-01	APC-45, Electronic Hook Switch, Cisco
87327-01	APD-80, Electronic Hook Switch
89280-11	APN-91, Electronic Hook Switch, NEC®
201081-01	APC-82, Electronic Hook Switch, Cisco
202578-01	APU-72, Electronic Hook Switch, Avaya (Nortel®)/Cisco
211076-01	APU-76 EHS Cable
212539-01	APA-24 Alcatel EHS Cable

VOYAGER LEGEND UC

Voyager Legend UC

IN THE BOX

VOYAGER LEGEND UC
Headset and eartips/foam eartip covers
Modular AC wall charger
Mini Bluetooth® USB adapter
Desktop charging stand
Portable charging case
USB charging cable
Micro USB charge adapter
Quick Start Guide

85117-01

85117-02

89031-01

89033-01

89034-01

89036-01

89037-01

89037-02

89037-03

SPARES AND REPLACEMENT PARTS

PART NO.	
85117-01	BT300-M mini Bluetooth USB adapter
85117-02	BT300 mini Bluetooth USB adapter
89031-01	Desktop charge stand
89033-01	Micro USB charge adapter (Includes Micro USB charge cable, 2')
89034-01	AC charger (NA only)
89036-01	Portable charge case (includes micro USB charge cable, 2')
89037-01	Small, 3-Pack, eartips/foam eartip covers
89037-02	Medium, 3-Pack, eartips/foam eartip covers
89037-03	Large, 3-Pack, eartips

89110-01

ACCESSORIES

89110-01	USB car charger

Voyager PRO UC

Voyager PRO UC, WG200/WG201/B

IN THE BOX

VOYAGER PRO UC

Headset and eartips/foam eartip covers
AC charging cable
Mini Bluetooth® USB adapter
Carrying case
USB charging cable
Quick Start Guide

VOYAGER PRO UC, WG200/WG201/B

Headset and eartips/foam eartip covers
AC charging cable
Bluetooth USB adapter
Quick Start Guide
USB charging cable

81292-01

81292-02

81292-03

82038-02

85117-01

85117-02

81293-01

SPARES AND REPLACEMENT PARTS

PART NO.	
81292-01	Small, 3-Pack, eartips/foam eartip covers
81292-02	Medium, 3-Pack, eartips/foam eartip covers
81292-03	Large, 3-Pack, eartips
82038-02	Carrying case (B230)
85117-01	BT300 mini Bluetooth USB adapter (B230, Microsoft version)
85117-02	BT300 mini Bluetooth USB adapter (B230)

ACCESSORIES

81293-01	Carrying case (WG200/WG201/B)

Accessories are available from your Poly reseller.

©2021 Plantronics, Inc. All rights reserved. Poly and the propeller design are trademarks of Plantronics, Inc. All other trademarks are the property of their respective owners. 7.21 835773