






Pre Moulded Reusable Ear Plugs




1 Grasp the stem of the plug behind the largest flange and pull the outer ear outwards and upwards.



2 Insert it into the ear canal with a gentle twisting and turning motion until a good seal is obtained.



3 Correct fit can be checked by alternately cupping your hand over your ear and then removing your hand. If the plug is sitting properly, you should not be able to notice any significant difference.



If the plug is not fitted or used correctly, its attenuation ability is reduced.

Occupational Health & Environmental Safety Group
3M United Kingdom plc
3M Centre
Cain Road, Bracknell
Berkshire RG12 8HT
Tel: 0870 60 800 60
www.3M.co.uk/ohes

Occupational Health & Environmental Safety Group
3M Ireland Ltd
The Iveagh Building,
The Park,
Carrickmines,
Dublin 18
Tel: 1800 320 500

Please recycle. Printed in the United Kingdom.
© 3M 2009. All rights reserved.
CHPREMOULDFP

