




The Herga USB footswitch is programmed by the user to simulate up to three simultaneous keystrokes. No software installation is required as it will be recognised by the operating system once plugged into a USB socket. Programming is done simply by setting small switches inside the footswitch having removed the cover. (See pages 2 and 3)

- Customer programmable USB footswitch
- Emulates keyboard functions, up to 3 keys simultaneously
- Plug and Play technology, no additional drivers required
- Grey cover and base
- 2.5m cable
- Works with Windows™, Linux™ & Mac™
- Rated 20mA 5V DC

Reference Dimensions



Specifications

- Power : 5V @ 20 mA
- Working temperature : 10~ 60°C
- Weight : 600g
- Moulded Glass filled nylon plastic construction
- Sealed to IPX2
- USB HID Compliant (No software drivers required)

Setting the Footswitch Function

Remove the base via the screws on the underside with a screwdriver. The base will then come away revealing the switches.

Find the Key (or combination of keys) you require on the tables below and set SW1 or 2 accordingly for each of the LEFT and RIGHT footswitches. For test purposes each footswitch is supplied with the switches set to the character 'a'.

Key	SW1	SW2	SW3
a	7	2	
b	4	5	
c	3	4	
d	7	4	
e	5	4	
f	7	5	
g	8	5	
h	8	6	
i	5	7	
j	7	6	
k	7	7	
l	7	8	
m	3	6	
n	4	6	
o	5	8	
p	5		5
q	5	2	
r	5	5	
s	7	3	
t	6	5	
u	5	6	
v	3	5	
w	5	3	
x	3	3	
y	6	6	
z	3	2	

Key	SW1	SW2	SW3
1 (!)	1	2	
2 (")	1	3	
3 (#)	1	4	
4 (\$)	1	5	
5 (%)	2	5	
6 (^)	2	6	
7 (&)	1	6	
8 (*)	1	7	
9 ((1	8	
0 ())	1		5

Key	SW1	SW2	SW3
F1	2	3	
F2	2	4	
F3	6	4	
F4	8	4	
F5	1	1	
F6	8	7	
F7	6	8	
F8	2	8	
F9	2		2
F10	1		2
F11	8		2
F12	4		2


Key	SW1	SW2	SW3
ESC	8	2	
TAB	6	2	
Space	8		1
Enter	3		2
Num Lock	3		1
Win	6		6
Caps Lock	6	3	
↑	8		7
↓	4		1
→	4		8
←	4		7
+ =	5		7
- _	4		9
*	3		9
/ ?	3		8
[{	4		5
] }	6	7	
: ;	7		5
~ #	3		5
. >	3	8	
, <	3	7	
~ `	2		5
= +	2	7	
\	8	3	
Back space	6		2
' @	8		5
Calc	6		3

Key	SW1	SW2	SW3
1 End	7		1
2 ↓	7		8
3PgDn	7		9
4 ←	6		1
5	6		8
6 →	6		9
7Home	5		1
8 ↑	5		8
9PgUp	5		9
0 Ins	8		8
. Del	8		9

Key	SW1	SW2	SW3
Page Up	7		3
Page Down	8		3
Home	2		7
End	1		7
Insert	2		8
Delete	2		1

Key	SW1	SW2	SW3
CTRL			10
ALT			11
SHIFT			12

Internal Switch Layout



Before replacing the footswitch lid test the required keystroke function. This is done by plugging the footswitch into a USB port on the PC and pressing each footswitch in turn.