

**PNOZ X10** 




Safety relays

This document is a translation of the original document.

All rights to this documentation are reserved by Pilz GmbH & Co. KG. Copies may be made for internal purposes. Suggestions and comments for improving this documentation will be gratefully received.

Source code from third-party manufacturers or open source software has been used for some components. The relevant licence information is available on the Internet on the Pilz homepage.

Pilz®, PIT®, PMI®, PNOZ®, Primo®, PSEN®, PSS®, PVIS®, SafetyBUS p®, SafetyEYE®, SafetyNET p®, the spirit of safety® are registered and protected trademarks of Pilz GmbH & Co. KG in some countries.



Introduction	4
Validity of documentation	4
Using the documentation	4
Definition of symbols	4
Safety	5
Intended use	5
Safety regulations	5
Safety assessment	5
Use of qualified personnel	5
Warranty and liability	6
Disposal	6
For your safety	6
Unit features	7
Safety features	7
Block diagram/terminal configuration	7
Types: AC	7
Type: DC	8
Function Description	8
Operating modes	8
Timing diagram	9
Installation	9
Wiring	10
Preparing for operation	11
Operation	13
Status indicators	14
Faults - Interference	14
Dimensions in mm	14
Technical details	15
Safety characteristic data	25
Supplementary data	
Service life graph	25
	<b>25</b> 25
	25
Order reference	
Order reference  EC declaration of conformity	25

### Introduction

### Validity of documentation

This documentation is valid for the product PNOZ X10. It is valid until new documentation is published.

This operating manual explains the function and operation, describes the installation and provides guidelines on how to connect the product.

### Using the documentation

This document is intended for instruction. Only install and commission the product if you have read and understood this document. The document should be retained for future reference.

### **Definition of symbols**

Information that is particularly important is identified as follows:



#### **DANGER!**

This warning must be heeded! It warns of a hazardous situation that poses an immediate threat of serious injury and death and indicates preventive measures that can be taken.



### **WARNING!**

This warning must be heeded! It warns of a hazardous situation that could lead to serious injury and death and indicates preventive measures that can be taken.



### **CAUTION!**

This refers to a hazard that can lead to a less serious or minor injury plus material damage, and also provides information on preventive measures that can be taken.



### **NOTICE**

This describes a situation in which the product or devices could be damaged and also provides information on preventive measures that can be taken. It also highlights areas within the text that are of particular importance.

PNOZ X10



### **INFORMATION**

This gives advice on applications and provides information on special features

### Safety

### Intended use

The safety relay PNOZ X10 provides a safety-related interruption of a safety circuit.

The safety relay meets the requirements of EN 60947-5-1, EN 60204-1 and VDE 0113-1 and may be used in applications with

- ▶ E-STOP pushbuttons
- Safety gates
- Light grids and safety switches with detection of shorts across contacts

The following is deemed improper use in particular:

- Any component, technical or electrical modification to the product
- Use of the product outside the areas described in this manual
- Use of the product outside the technical details (see Technical details [44] 15]).



### **NOTICE**

EMC-compliant electrical installation

The product is designed for use in an industrial environment. The product may cause interference if installed in other environments. If installed in other environments, measures should be taken to comply with the applicable standards and directives for the respective installation site with regard to interference.

### Safety regulations

### Safety assessment

Before using a unit it is necessary to perform a safety assessment in accordance with the Machinery Directive.

Functional safety is guaranteed for the product as a single component. However, this does not guarantee the functional safety of the overall plant/machine. In order to achieve the required safety level for the overall plant/machine, define the safety requirements for the plant/machine and then define how these must be implemented from a technical and organisational standpoint.

### Use of qualified personnel

The products may only be assembled, installed, programmed, commissioned, operated, maintained and decommissioned by competent persons.

A competent person is someone who, because of their training, experience and current professional activity, has the specialist knowledge required to test, assess and operate the work equipment, devices, systems, plant and machinery in accordance with the general standards and guidelines for safety technology.

It is the company's responsibility only to employ personnel who:

- Are familiar with the basic regulations concerning health and safety / accident prevention
- Have read and understood the information provided in this description under "Safety"
- And have a good knowledge of the generic and specialist standards applicable to the specific application.

### Warranty and liability

All claims to warranty and liability will be rendered invalid if

- The product was used contrary to the purpose for which it is intended
- Damage can be attributed to not having followed the guidelines in the manual
- Operating personnel are not suitably qualified
- Any type of modification has been made (e.g. exchanging components on the PCB boards, soldering work etc.).

### **Disposal**

- In safety-related applications, please comply with the mission time T<sub>M</sub> in the safety-related characteristic data.
- When decommissioning, please comply with local regulations regarding the disposal of electronic devices (e.g. Electrical and Electronic Equipment Act).

### For your safety

The unit meets all the necessary conditions for safe operation. However, please note the following:

Note for overvoltage category III: If voltages higher than low voltage (>50 VAC or >120 VDC) are present on the unit, connected control elements and sensors must have a rated insulation voltage of at least 250 V.

### **Unit features**

- Positive-guided relay outputs:
  - 6 safety contacts (N/O), instantaneous
  - 4 auxiliary contacts (N/C), instantaneous
- Connection options for:
  - E-STOP pushbuttons
  - Safety gate limit switches
  - Start buttons
  - Light grids and safety switches with detection of shorts across contacts
- LED display for:
  - Supply voltage
  - Switch status of the safety contacts
- See order reference for unit types

### Safety features


The safety relay meets the following safety requirements:

- The circuit is redundant with built-in self-monitoring.
- The safety function remains effective in the case of a component failure.
- The correct opening and closing of the safety function relays is tested automatically in each on-off cycle.

### Block diagram/terminal configuration

### Types: AC


- U<sub>B</sub>: 24 VAC; Order no. 774700
- U<sub>B</sub>: 42 VAC; Order no. 774701
- U<sub>B</sub>: 110 120 VAC; Order no. 774703
- U<sub>B</sub>: 230 240 VAC; Order no. 774706



\*Insulation between the non-marked area and the relay contacts: Basic insulation (over-voltage category III), Protective separation (overvoltage category II)

### Type: DC

U<sub>B</sub>: 24 VDC; Order no. 774709



<sup>\*</sup>Insulation between the non-marked area and the relay contacts: Basic insulation (over-voltage category III), Protective separation (overvoltage category II)

### **Function Description**

The safety relay PNOZ X10 provides a safety-oriented interruption of a safety circuit. When supply voltage is supplied the "POWER" LED is lit. The unit is ready for operation when the feedback loop Y1-Y2 and the start circuit S12-S34 are closed.


- Input circuit is closed (e.g. E-STOP pushbutton is not operated):
  - The LEDs "CH.1" and "CH.2" are lit.
  - Safety contacts 13-14, 23-24, 33-34, 43-44, 53-54 and 63-64 are closed, auxiliary contacts 71-72, 81-82, 91-92 and 01-02 are opened. The unit is active.
- Input circuit is opened (e.g. E-STOP pushbutton operated):
  - The LEDs "CH.1" and "CH.2" go out.
  - Safety contacts 13-14, 23-24, 33-34, 43-44, 53-54 and 63-64 are opened redundantly, auxiliary contacts 71-72, 81-82, 91-92 and 01-02 are closed.

### **Operating modes**

- Single-channel operation: No redundancy in the input circuit, earth faults in the start and input circuit are detected.
- Dual-channel operation with detection of shorts across contacts: Redundant input circuit, PNOZ X10 detects
  - earth faults in the start and input circuit,
  - short circuits in the input circuit,
  - shorts across contacts in the input circuit.
- Dual-channel operation without detection of shorts across contacts: Redundant input circuit, detects PNOZ X10
  - earth faults in the start and input circuit,
  - short circuits in the input circuit.
- Automatic start: Unit is active once the input circuit has been closed.
- Manual start: Unit is active once the input circuit and the start circuit are closed.

- Monitored start: Unit is active once
  - the input circuit is closed and then the start circuit is closed and opened again.
  - the start circuit is closed and then opened again once the input circuit is closed.
- Increase in the number of available contacts by connecting contact expander modules or external contactors/relays.

### **Timing diagram**



### Legend

Power: Supply voltage

Start: Start circuit

Input: Input circuit

Output safe: Safety contacts

Output aux: Auxiliary contacts

[1]: Automatic start

[2]: Manual start

[3]: Monitored start

a: Input circuit closes before start circuit

b: Start circuit closes before input circuit

t₁: Switch-on delay

t<sub>2</sub>: Delay-on de-energisation

t₃: Recovery time

### Installation

- The unit should be installed in a control cabinet with a protection type of at least IP54.
- Use the notch on the rear of the unit to attach it to a DIN rail.
- Ensure the unit is mounted securely on a vertical DIN rail (35 mm) by using a fixing element (e.g. retaining bracket or an end angle).

PNOZ X10

### Wiring

#### Please note:

- Information given in the "Technical details [ 15] must be followed.
- Outputs 13-14, 23-24, 33-34, 43-44, 53-54, 63-64 are safety contacts; outputs 71-72, 81-82, 91-92, 01-02 are auxiliary contacts (e.g. for display).
- Do not use auxiliary contacts 71-72, 81-82, 91-92, 01-02 for safety circuits!
- Do not connect undesignated terminals.
- To prevent contact welding, a fuse should be connected before the output contacts (see Technical details [44 15]).
- Calculation of the max. cable runs I<sub>max</sub> in the input circuit:

$$I_{max} = \frac{R_{lmax}}{R_l / km}$$

 $R_{lmax}$  = max. overall cable resistance (see Technical details [ 15])  $R_{l}$  / km = cable resistance/km

- ▶ Use copper wire that can withstand 60/75 °C.
- Do not switch low currents using contacts that have been used previously with high currents.
- Sufficient fuse protection must be provided on all output contacts with capacitive and inductive loads.
- When connecting magnetically operated, reed proximity switches, ensure that the max. peak inrush current (on the input circuit) does not overload the proximity switch.
- On 24 VDC devices:
  - The power supply must comply with the regulations for extra low voltages with protective electrical separation (SELV, PELV) in accordance with VDE 0100, Part 410.
- Ensure the wiring and EMC requirements of IEC 60204-1 are met.

### Important for detection of shorts across contacts:

As this function for detecting shorts across contacts is not failsafe, it is tested by Pilz during the final control check. If there is a danger of exceeding the cable runs, we recommend the following test after the installation of the device:

- 1. Unit ready for operation (output contacts closed)
- 2. Short circuit the test terminals S12, S22 for detecting shorts across the inputs.
- 3. The unit's fuse must be triggered and the output contacts must open. Cable lengths in the scale of the maximum length can delay the fuse triggering for up to 2 minutes.
- 4. Reset the fuse: remove the short circuit and switch off the supply voltage for approx. 1 minute.

## **Preparing for operation**

AC	DC
L	.1
A2 \$\documer_1	
	E   A2   L-
	A1 \$\documents \text{A2} \text{A2} \text{A2}

Input circuit	Single-channel	Dual-channel
E-STOP without detection of shorts across contacts	S12 O S1 TH S12 O S12 O S12 O S12 S11 O S22 O S2	S11 0 S1 T <sub>r</sub> S11 0 S1 T <sub>r</sub> S12
E-STOP with detection of shorts across contacts		S11 0 S1 Ty S11 0 S11 0 S1 Ty S12 0 S12 0 S12 0
Safety gate without detection of shorts across contacts	S12 0 S1 S12 0 S1 O Y3 S21 O S22 O	S11 0 S1 S2 S12 O Y3 0
Safety gate with detection of shorts across contacts		S11 \$\frac{1}{\sqrt{S1}}\$ \$\frac{1}{\sqrt{S2}}\$ \$\frac{1}{S2
Light guards or safety switch, detection of shorts across contacts via ESPE (only when $U_B = 24 \text{ VDC}$ )		S22 24 V DC



### **NOTICE**

With single-channel wiring the safety level of your machine/plant may be lower than the safety level of the unit (see Safety characteristic data [25]).



### **NOTICE**

Operation with a light guard or safety switch

It must not be possible to switch off the supply voltage for the PNOZ X10 separately from the supply voltage for the light guard or safety switch.

Start circuit	Single-channel, dual-channel without detection of shorts across contacts	Dual-channel with detection of shorts across contacts
Automatic start	\$33 ¢ \$ Y1 \$ \$37 \$ \$34 ¢	S12 ¢  † Y1  † S37  S34 ¢
Automatic start with start-up test	\$37 \$33 \$3 \$51 \$2 \$51 \$52 \$53 \$53 \$53 \$53 \$53 \$53 \$53 \$53 \$53 \$53	
Manual start	S33 0 S37 S34 0 S34 0	S12 0
Monitored start	S33 0 S34 0 Y1 0 S37 0	S12 0 S34 0 Y1 0 S37 0



### **NOTICE**

In the event of an automatic start or manual start with bridged start contact (fault):

The unit starts up automatically when the safeguard is reset, e.g. when the E-STOP pushbutton is released. Use external circuit measures to prevent an unexpected restart.

Feedback loop	Without feedback loop monit- oring	With feedback loop monitoring
Link or contacts from external contactors	Y1 \$\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Y1

### Legend

- ▶ S1/S2: E-STOP/safety gate switch
- S3: Reset button
- ► ↑: Switch operated
- : Gate open
- Gate closed



### **INFORMATION**

With automatic start and manual start, Y1 and S37 must not be linked.

### Operation



### **NOTICE**

Check each safety function

- after initial commissioning and after each change of the machine/ plant
- for SIL CL 3/PL e at least 1x per month, for SIL CL 2/PL d at least 1x per year

Follow the instructions below:

- Activate the safety function and check whether all the used safety contacts open.
- Prepare for operation again and start the unit. All the used safety contacts must be closed again.

The safety functions may only be checked by qualified personnel.

### Status indicators

LEDs indicate the status and errors during operation:

LED on

POWER

Supply voltage is present.

\_\_\_\_\_ CH.1


Safety contacts of channel 1 are closed.

CH.2
Safety contacts of channel 2 are closed.

### Faults - Interference

- Earth fault: The supply voltage fails and the safety contacts open. Once the cause of the respective fault has been rectified and the supply voltage is switched off for approx. 1 minute, the unit is ready for operation again.
- Contact malfunctions: If the contacts have welded, reactivation will not be possible after the input circuit has opened.
- ▶ LED "POWER" does not light: Short circuit or no supply voltage.

### **Dimensions in mm**



### **Technical details**

Order no. 774700 - 774703

See below for more order numbers

Approvals		w for more order numbers		
Approvals   ian), TÜV, cULus Listed   ian), TÜV, culus   ian land	General	774700	774701	774703
Supply voltage	Approvals			CCC, CE, EAC (Eurasian), TÜV, cULus Listed
Voltage	Electrical data	774700	774701	774703
Kind         AC         AC         AC         AC           Voltage tolerance         -15 %/+10 %         -15 %/+10 %         -15 %/+10 %           Output of external power supply (AC)         10 VA         10 VA         10 VA           Frequency range AC         50 - 60 Hz         50 - 60 Hz         50 - 60 Hz           Duty cycle         100 %         100 %         100 %           Inputs         774700         774701         774703           Number         2         2         2           Voltage at Input circuit DC         24 V         24 V         24 V           Start circuit DC         24 V         24 V         24 V           Start circuit DC         24 V         24 V         24 V           Current at Input circuit DC         50 mA         50 mA         50 mA           Start circuit DC         100 mA         100 mA         100 mA           Feedback loop DC         100 mA         100 mA         100 mA           Min. input resistance at power-on         89 Ohm         89 Ohm         89 Ohm           Max. overall cable resistance Rimax         Single-channel at UB AC         45 Ohm         45 Ohm         45 Ohm           Dual-channel with detection of shorts across contacts at UB AC	Supply voltage			
Kind         AC         AC         AC         AC           Voltage tolerance         -15 %/+10 %         -15 %/+10 %         -15 %/+10 %           Output of external power supply (AC)         10 VA         10 VA         10 VA           Frequency range AC         50 - 60 Hz         50 - 60 Hz         50 - 60 Hz           Duty cycle         100 %         100 %         100 %           Inputs         774700         774701         774703           Number         2         2         2           Voltage at Input circuit DC         24 V         24 V         24 V           Start circuit DC         24 V         24 V         24 V           Start circuit DC         24 V         24 V         24 V           Current at Input circuit DC         50 mA         50 mA         50 mA           Start circuit DC         100 mA         100 mA         100 mA           Feedback loop DC         100 mA         100 mA         100 mA           Min. input resistance at power-on         89 Ohm         89 Ohm         89 Ohm           Max. overall cable resistance Rimax         Single-channel at UB AC         45 Ohm         45 Ohm         45 Ohm           Dual-channel with detection of shorts across contacts at UB AC	Voltage	24 V	42 V	110 - 120 V
Output of external power supply (AC)         10 VA         10 VA         10 VA           Frequency range AC         50 - 60 Hz         50 - 60 Hz         50 - 60 Hz           Duty cycle         100 %         100 %         100 %           Inputs         774700         774701         774703           Number         2         2         2           Voltage at Input circuit DC         24 V         24 V         24 V           Start circuit DC         24 V         24 V         24 V           Feedback loop DC         24 V         24 V         24 V           Current at Input circuit DC         50 mA         50 mA         50 mA           Start circuit DC         100 mA         100 mA         100 mA           Hin. input resistance at power-on         89 Ohm         89 Ohm         89 Ohm           Max. overall cable resistance Rimax         Single-channel at UB AC         45 Ohm         45 Ohm         45 Ohm           Dual-channel without detection of shorts across contacts at UB AC         90 Ohm         90 Ohm         90 Ohm         90 Ohm           Dual-channel with detection of shorts across contacts at UB AC         15 Ohm         15 Ohm         15 Ohm         15 Ohm           Relay outputs         774700         774701 <td>•</td> <td>AC</td> <td>AC</td> <td>AC</td>	•	AC	AC	AC
Output of external power supply (AC)         10 VA         10 VA         10 VA           Frequency range AC         50 - 60 Hz         50 - 60 Hz         50 - 60 Hz           Duty cycle         100 %         100 %         100 %           Inputs         774700         774701         774703           Number         2         2         2           Voltage at Input circuit DC         24 V         24 V         24 V           Start circuit DC         24 V         24 V         24 V           Feedback loop DC         24 V         24 V         24 V           Current at Input circuit DC         50 mA         50 mA         50 mA           Start circuit DC         100 mA         100 mA         100 mA           Hin. input resistance at power-on         89 Ohm         89 Ohm         89 Ohm           Max. overall cable resistance Rimax         Single-channel at UB AC         45 Ohm         45 Ohm         45 Ohm           Dual-channel without detection of shorts across contacts at UB AC         90 Ohm         90 Ohm         90 Ohm         90 Ohm           Dual-channel with detection of shorts across contacts at UB AC         15 Ohm         15 Ohm         15 Ohm         15 Ohm           Relay outputs         774700         774701 <td>Voltage tolerance</td> <td>-15 %/+10 %</td> <td>-15 %/+10 %</td> <td>-15 %/+10 %</td>	Voltage tolerance	-15 %/+10 %	-15 %/+10 %	-15 %/+10 %
Dower supply (AC)	•			
Duty cycle	•	10 VA	10 VA	10 VA
Inputs	Frequency range AC	50 - 60 Hz	50 - 60 Hz	50 - 60 Hz
Inputs	Duty cycle	100 %	100 %	100 %
Number   2		774700	774701	774703
Input circuit DC	•	2	2	2
Input circuit DC				
Start circuit DC	•	24 V	24 V	24 V
Feedback loop DC 24 V 24 V 24 V  Current at Input circuit DC 50 mA 50 mA 50 mA Start circuit DC 100 mA 100 mA 100 mA Feedback loop DC 100 mA 100 mA 100 mA  Min. input resistance at power-on 89 Ohm 89 Ohm 89 Ohm  Max. overall cable resistance RImax Single-channel at UB AC 45 Ohm 45 Ohm 45 Ohm  Dual-channel without detection of shorts across contacts at UB AC 90 Ohm 90 Ohm 90 Ohm  Dual-channel with detection of shorts across contacts at UB AC 15 Ohm 15 Ohm  Relay outputs 774700 774701 774703  Number of output contacts	•			
Current at Input circuit DC 50 mA 50 mA 100 mA Start circuit DC 100 mA 100 mA 100 mA Feedback loop DC 100 mA 100 mA 100 mA Min. input resistance at power-on 89 Ohm 89 Ohm 89 Ohm Max. overall cable resistance RImax Single-channel at UB AC 45 Ohm 45 Ohm 45 Ohm Dual-channel without detection of shorts across contacts at UB AC 90 Ohm 90 Ohm 90 Ohm Dual-channel with detection of shorts across contacts at UB AC 15 Ohm 15 Ohm Relay outputs 774700 774701 774703  Number of output contacts				
Input circuit DC 50 mA 50 mA 100 mA 100 mA 100 mA Feedback loop DC 100 mA 100 mA 100 mA 100 mA  Min. input resistance at power-on 89 Ohm 89 Ohm 89 Ohm  Max. overall cable resistance RImax  Single-channel at UB AC 45 Ohm 45 Ohm 45 Ohm  Dual-channel without detection of shorts across contacts at UB AC 90 Ohm 90 Ohm 90 Ohm  Dual-channel with detection of shorts across contacts at UB AC 15 Ohm 15 Ohm  Relay outputs 774700 774701 774703  Number of output contacts				
Start circuit DC 100 mA 100 mA 100 mA 100 mA 100 mA Feedback loop DC 100 mA 100 mA 100 mA  Min. input resistance at power-on 89 Ohm 89 Ohm 89 Ohm  Max. overall cable resistance RImax  Single-channel at UB AC 45 Ohm 45 Ohm 45 Ohm  Dual-channel without detection of shorts across contacts at UB AC 90 Ohm 90 Ohm  Dual-channel with detection of shorts across contacts at UB AC 15 Ohm 15 Ohm  Relay outputs 774700 774701 774703  Number of output contacts		50 mΔ	50 m∆	50 mΔ
Feedback loop DC 100 mA 100 mA 100 mA  Min. input resistance at power-on 89 Ohm 89 Ohm 89 Ohm  Max. overall cable resistance RImax  Single-channel at UB AC 45 Ohm 45 Ohm 45 Ohm  Dual-channel without detection of shorts across contacts at UB AC 90 Ohm 90 Ohm  Dual-channel with detection of shorts across contacts at UB AC 15 Ohm 15 Ohm  Relay outputs 774700 774701 774703  Number of output contacts	•			
Min. input resistance at power-on 89 Ohm 89 Ohm 89 Ohm  Max. overall cable resistance RImax  Single-channel at UB AC 45 Ohm 45 Ohm  Dual-channel without detection of shorts across contacts at UB AC 90 Ohm  Dual-channel with detection of shorts across contacts at UB AC 15 Ohm 15 Ohm  Relay outputs 774700 774701 774703  Number of output contacts				
Max. overall cable resistance RImax  Single-channel at UB AC  Dual-channel without detection of shorts across contacts at UB AC  Dual-channel with detection of shorts across contacts at UB AC  Dual-channel with detection of shorts across contacts at UB AC  Dual-channel with detection of shorts across contacts at UB AC  To hom  15 Ohm  Relay outputs  774700  774701  774703	<u> </u>	100 1117	100 IIIA	TOO HIM
Max. overall cable resistance RImax  Single-channel at UB  AC  45 Ohm  Dual-channel without detection of shorts across contacts at UB  AC  90 Ohm  Dual-channel with detection of shorts across contacts at UB AC  Tolerance RImax  45 Ohm  45 Ohm  90 Ohm  90 Ohm  15 Ohm  Relay outputs  774700  774701  774703  Number of output contacts	•	89 Ohm	89 Ohm	89 Ohm
AC 45 Ohm 45 Ohm  Dual-channel without detection of shorts across contacts at UB AC 90 Ohm 90 Ohm  Dual-channel with detection of shorts across contacts at UB AC 15 Ohm 15 Ohm  Relay outputs 774700 774701 774703  Number of output contacts	Max. overall cable resist-			
across contacts at UB AC 90 Ohm 90 Ohm 90 Ohm Dual-channel with detection of shorts across contacts at UB AC 15 Ohm 15 Ohm Relay outputs 774700 774701 774703  Number of output contacts	AC Dual-channel without	45 Ohm	45 Ohm	45 Ohm
tection of shorts across contacts at UB AC 15 Ohm 15 Ohm 15 Ohm  Relay outputs 774700 774701 774703  Number of output contacts	across contacts at UB AC	90 Ohm	90 Ohm	90 Ohm
Relay outputs 774700 774701 774703  Number of output contacts	tection of shorts across			
Number of output contacts	contacts at UB AC			
tacts	Relay outputs	774700	774701	774703
	•			
Safety contacts (N/O),				
instantaneous 6 6 6				
Auxiliary contacts (N/C) 4 4 4		4	4	4
Max. short circuit current IK 1 kA 1 kA 1 kA		1 kA	1 kA	1 kA

Relay outputs	774700	774701	774703
Utilisation category			
In accordance with the			
standard	EN 60947-4-1	EN 60947-4-1	EN 60947-4-1
Utilisation category of safety contacts			
AC1 at	400 V	400 V	400 V
Min. current	0,01 A	0,01 A	0,01 A
Max. current	5 A	5 A	5 A
Max. power	2000 VA	2000 VA	2000 VA
AC1 at	240 V	240 V	240 V
Min. current	0,01 A	0,01 A	0,01 A
Max. current	8 A	8 A	8 A
Max. power	2000 VA	2000 VA	2000 VA
DC1 at	24 V	24 V	24 V
Min. current	0,01 A	0,01 A	0,01 A
Max. current	8 A	8 A	8 A
Max. power	200 W	200 W	200 W
Utilisation category of auxiliary contacts			
AC1 at	240 V	240 V	240 V
Min. current	0,01 A	0,01 A	0,01 A
Max. current	8 A	8 A	8 A
Max. power	2000 VA	2000 VA	2000 VA
DC1 at	24 V	24 V	24 V
Min. current	0,01 A	0,01 A	0,01 A
Max. current	8 A	8 A	8 A
Max. power	200 W	200 W	200 W
Utilisation category			
In accordance with the standard	EN 60947-5-1	EN 60947-5-1	EN 60947-5-1
Utilisation category of safety contacts			
AC15 at	230 V	230 V	230 V
Max. current	5 A	5 A	5 A
DC13 (6 cycles/min) at		24 V	24 V
Max. current	7 A	7 A	7 A
Utilisation category of auxiliary contacts			
AC15 at	230 V	230 V	230 V
Max. current	5 A	5 A	5 A
DC13 (6 cycles/min) at		24 V	24 V
Max. current	7 A	7 A	7 A

Relay outputs	774700	774701	774703
Utilisation category in accordance with UL			
Voltage	240 V AC G. P.	240 V AC G. P.	240 V AC G. P.
With current	8 A	8 A	8 A
Voltage	24 V DC Resistive	24 V DC Resistive	24 V DC Resistive
With current	5 A	5 A	5 A
Pilot Duty	B300, R300	B300, R300	B300, R300
External contact fuse protection, safety contacts			
In accordance with the standard	EN 60947-5-1	EN 60947-5-1	EN 60947-5-1
Max. melting integral	240 A²s	240 A <sup>2</sup> s	240 A²s
Blow-out fuse, quick	10 A	10 A	10 A
Blow-out fuse, slow	6 A	6 A	6 A
Blow-out fuse, gG	10 A	10 A	10 A
Circuit breaker 24V AC/DC, characteristic B/C	6 A	6 A	6 A
External contact fuse pro-			
tection, auxiliary contacts			
Max. melting integral	240 A <sup>2</sup> s	240 A <sup>2</sup> s	240 A <sup>2</sup> s
Blow-out fuse, quick	10 A	10 A	10 A
Blow-out fuse, slow	6 A	6 A	6 A
Blow-out fuse, gG	10 A	10 A	10 A
Circuit breaker 24 V AC/DC, characteristic B/C	6 A	6 A	6 A
Contact material	AgSnO2 + 0,2 μm Au	AgSnO2 + 0,2 μm Au	AgSnO2 + 0,2 μm Au
Conventional thermal	774700	774701	774703
current while loading several contacts	774700	774701	774703
Ith per contact at UB AC; AC1: 240 V, DC1: 24 V			
Conv. therm. current with 1 contact	8 A	8 A	8 A
Conv. therm. current with 2 contacts	7 A	7 A	7 A
Conv. therm. current with 3 contacts	5,6 A	5,6 A	5,6 A
Conv. therm. current with 4 contacts	4,9 A	4,9 A	4,9 A
Conv. therm. current with 5 contacts	4,4 A	4,4 A	4,4 A
Conv. therm. current with 6 contacts	4 A	4 A	4 A

Times	774700	774701	774703
Switch-on delay			
With automatic start			
typ.	180 ms	180 ms	180 ms
With automatic start			
max.	250 ms	250 ms	250 ms
With automatic start			
after power on typ.	200 ms	200 ms	200 ms
With automatic start	300 ms	300 ms	300 ms
after power on max.	200 ms	200 ms	200 ms
With manual start typ.		250 ms	250 ms
With manual start max.	250 IIIS	250 IIIS	250 IIIS
With monitored start typ.	150 ms	150 ms	150 ms
With monitored start	100 1110	100 1110	100 mo
max.	200 ms	200 ms	200 ms
Delay-on de-energisation			
With E-STOP typ.	20 ms	20 ms	20 ms
With E-STOP max.	30 ms	30 ms	30 ms
With power failure typ.	170 ms	170 ms	170 ms
With power failure max.	250 ms	250 ms	250 ms
Recovery time at max.			
switching frequency 1/s			
After E-STOP	50 ms	50 ms	50 ms
After power failure	300 ms	300 ms	300 ms
Min. start pulse duration			
with a monitored start	50 ms	50 ms	50 ms
Supply interruption before	25 ma	25 ma	35 ms
de-energisation	35 ms	35 ms	'.
Environmental data	774700	774701	774703
Climatic suitability	EN 60068-2-78	EN 60068-2-78	EN 60068-2-78
Ambient temperature	40	40	40 00
Temperature range	-10 - 55 °C	-10 - 55 °C	-10 - 55 °C
Storage temperature			
Temperature range	-40 - 85 °C	-40 - 85 °C	-40 - 85 °C
Climatic suitability			
Humidity	93 % r. h. at 40 °C	93 % r. h. at 40 °C	93 % r. h. at 40 °C
Condensation during op-	Not normalitied	Not no maitted	Not normitted
eration	Not permitted	Not permitted	Not permitted
EMC	EN 60947-5-1, EN 61000-6-2, EN 61326-3-1	EN 60947-5-1, EN 61000-6-2, EN 61326-3-1	EN 60947-5-1, EN 61000-6-2, EN 61326-3-1
Vibration			
In accordance with the	EN 00000 0 0	EN 00000 0 0	EN 00000 0 C
standard	EN 60068-2-6	EN 60068-2-6	EN 60068-2-6
Frequency	10 - 55 Hz	10 - 55 Hz	10 - 55 Hz
Amplitude	0,35 mm	0,35 mm	0,35 mm

Environmental data	774700	774701	774703
Airgap creepage			
In accordance with the			
standard	EN 60947-1	EN 60947-1	EN 60947-1
Overvoltage category	III / II	III / II	III / II
Pollution degree	2	2	2
Rated insulation voltage	250 V	250 V	250 V
Rated impulse withstand voltage	4 kV	4 kV	4 kV
Protection type			
Mounting area (e.g. control cabinet)	IP54	IP54	IP54
Housing	IP40	IP40	IP40
Terminals	IP20	IP20	IP20
Mechanical data	774700	774701	774703
Mounting position	Any	Any	Any
Mechanical life	10,000,000 cycles	10,000,000 cycles	10,000,000 cycles
Material			
Bottom	PPO UL 94 V0	PPO UL 94 V0	PPO UL 94 V0
Front	ABS UL 94 V0	ABS UL 94 V0	ABS UL 94 V0
Тор	PPO UL 94 V0	PPO UL 94 V0	PPO UL 94 V0
Connection type	Screw terminal	Screw terminal	Screw terminal
Mounting type	Fixed	Fixed	Fixed
Conductor cross section with screw terminals			
1 core flexible	0,2 - 4 mm², 24 - 10 AWG	6 0,2 - 4 mm², 24 - 10 AWG	0,2 - 4 mm <sup>2</sup> , 24 - 10 AWG
2 core with the same cross section, flexible with crimp connectors, no plastic sleeve	0,2 - 2,5 mm², 24 - 14 AWG	0,2 - 2,5 mm², 24 - 14 AWG	0,2 - 2,5 mm², 24 - 14 AWG
2 core with the same cross section, flexible without crimp connectors or with TWIN crimp connectors	0,2 - 2,5 mm², 24 - 14 AWG	0,2 - 2,5 mm², 24 - 14 AWG	0,2 - 2,5 mm², 24 - 14 AWG
Torque setting with screw terminals	0,6 Nm	0,6 Nm	0,6 Nm
Dimensions			
Height	87 mm	87 mm	87 mm
Width	90 mm	90 mm	90 mm
Depth	121 mm	121 mm	121 mm
Weight	720 g	720 g	720 g

Where standards are undated, the 2014-07 latest editions shall apply.

### Order no. 774706 - 774709

General	774706	774709
Approvals	CCC, CE, EAC (Eurasian), TÜV, cULus Listed	CCC, CE, EAC (Eurasian), TÜV, cULus Listed
Electrical data	774706	774709
Supply voltage		
Voltage	230 - 240 V	24 V
Kind	AC	DC
Voltage tolerance	-15 %/+10 %	-15 %/+10 %
Output of external power supply (AC)	10 VA	-
Output of external power supply (DC)	_	5,5 W
Frequency range AC	50 - 60 Hz	_
Residual ripple DC	_	160 %
Duty cycle	100 %	100 %
Inputs	774706	774709
Number	2	2
Voltage at		
Input circuit DC	24 V	24 V
Start circuit DC	24 V	24 V
Feedback loop DC	24 V	24 V
Current at		
Input circuit DC	50 mA	50 mA
Start circuit DC	100 mA	100 mA
Feedback loop DC	100 mA	100 mA
Min. input resistance at power-on	89 Ohm	89 Ohm
Max. overall cable resistance Rl-max		
Single-channel at UB DC	_	45 Ohm
Single-channel at UB AC	45 Ohm	_
Dual-channel without detection of shorts across contacts at UB DC	_	90 Ohm
Dual-channel without detection of shorts across contacts at UB AC	90 Ohm	_
Dual-channel with detection of shorts across contacts at UB DC	; –	15 Ohm
Dual-channel with detection of shorts across contacts at UB AC	15 Ohm	_
Relay outputs	774706	774709
Number of output contacts		
Safety contacts (N/O), instant- aneous	6	6
Auxiliary contacts (N/C)	4	4
Max. short circuit current IK	1 kA	1 kA
	•	

Relay outputs	774706	774709	
Utilisation category			
In accordance with the standard	EN 60947-4-1	EN 60947-4-1	
Utilisation category of safety con-			
tacts			
AC1 at	400 V	400 V	
Min. current	0,01 A	0,01 A	
Max. current	5 A	5 A	
Max. power	2000 VA	2000 VA	
AC1 at	240 V	240 V	
Min. current	0,01 A	0,01 A	
Max. current	8 A	8 A	
Max. power	2000 VA	2000 VA	
DC1 at	24 V	24 V	
Min. current	0,01 A	0,01 A	
Max. current	8 A	8 A	
Max. power	200 W	200 W	
Utilisation category of auxiliary contacts	-		
AC1 at	240 V	240 V	
Min. current	0,01 A	0,01 A	
Max. current	8 A	8 A	
Max. power	2000 VA	2000 VA	
DC1 at	24 V	24 V	
Min. current	0,01 A	0,01 A	
Max. current	8 A	8 A	
Max. power	200 W	200 W	
Utilisation category			
In accordance with the standard	EN 60947-5-1	EN 60947-5-1	
Utilisation category of safety contacts			
AC15 at	230 V	230 V	
Max. current	5 A	5 A	
DC13 (6 cycles/min) at	24 V	24 V	
Max. current	7 A	7 A	
Utilisation category of auxiliary contacts	-		
AC15 at	230 V	230 V	
Max. current	5 A	5 A	
DC13 (6 cycles/min) at	24 V	24 V	
Max. current	7 A	7 A	
-			

Relay outputs	774706	774709	
Utilisation category in accordance with UL			
Voltage	240 V AC G. P.	240 V AC G. P.	
With current	8 A	8 A	
Voltage	24 V DC Resistive	24 V DC Resistive	
With current	5 A	5 A	
Pilot Duty	B300, R300	B300, R300	
External contact fuse protection, safety contacts			
In accordance with the standard	EN 60947-5-1	EN 60947-5-1	
Max. melting integral	240 A <sup>2</sup> s	240 A <sup>2</sup> s	
Blow-out fuse, quick	10 A	10 A	
Blow-out fuse, slow	6 A	6 A	
Blow-out fuse, gG	10 A	10 A	
Circuit breaker 24V AC/DC, characteristic B/C	6 A	6 A	
External contact fuse protection, auxiliary contacts			
Max. melting integral	240 A²s	240 A²s	
Blow-out fuse, quick	10 A	10 A	
Blow-out fuse, slow	6 A	6 A	
Blow-out fuse, gG	10 A	10 A	
Circuit breaker 24 V AC/DC,			
characteristic B/C	6 A	6 A	
Contact material	AgSnO2 + 0,2 μm Au	AgSnO2 + 0,2 μm Au	
Conventional thermal current while loading several contacts	774706	774709	
Ith per contact at UB AC; AC1: 240 V, DC1: 24 V			
Conv. therm. current with 1 contact	8 A	_	
Conv. therm. current with 2 contacts	7 A	_	
Conv. therm. current with 3 contacts	5,6 A	_	
Conv. therm. current with 4 contacts	4,9 A	_	
Conv. therm. current with 5 contacts	4,4 A	_	
Conv. therm. current with 6 contacts	4 A	_	

Conventional thermal current while loading several contacts	774706	774709
Ith per contact at UB DC; AC1: 240 V, DC1: 24 V		
Conv. therm. current with 1 contact	_	8 A
Conv. therm. current with 2 contacts	_	8 A
Conv. therm. current with 3 contacts	_	7 A
Conv. therm. current with 4 contacts	_	6,1 A
Conv. therm. current with 5 contacts	- 5,4 A	
Conv. therm. current with 6 contacts	_	5 A
Times	774706	774709
Switch-on delay		
With automatic start typ.	180 ms	190 ms
With automatic start max.	250 ms	250 ms
With automatic start after power		
on typ.	200 ms	200 ms
With automatic start after power	200	200
on max.	300 ms	300 ms
With manual start typ.	200 ms	200 ms
With manual start max.	250 ms	250 ms
With monitored start typ.	150 ms	165 ms
With monitored start max.	200 ms	220 ms
Delay-on de-energisation	20	20
With E-STOP may	20 ms	20 ms
With E-STOP max.	30 ms	30 ms
With power failure typ.	170 ms	170 ms
With power failure max.	250 ms	250 ms
Recovery time at max. switching frequency 1/s		
After E-STOP	50 ms	50 ms
After power failure	300 ms	300 ms
Min. start pulse duration with a monitored start	50 ms	50 ms
Supply interruption before de-energisation	35 ms	35 ms
Environmental data	774706	774709
Climatic suitability	EN 60068-2-78	EN 60068-2-78
Ambient temperature		
Temperature range	-10 - 55 °C	-10 - 55 °C
Storage temperature		
Temperature range	-40 - 85 °C	-40 - 85 °C
Climatic suitability		
Humidity	93 % r. h. at 40 °C	93 % r. h. at 40 °C

Environmental data	774706	774709
Condensation during operation	Not permitted	Not permitted
EMC	EN 60947-5-1, EN 61000-6-2, EN 61326-3-1	EN 60947-5-1, EN 61000-6-2, EN 61326-3-1
Vibration		
In accordance with the standard	EN 60068-2-6	EN 60068-2-6
Frequency	10 - 55 Hz	10 - 55 Hz
Amplitude	0,35 mm	0,35 mm
Airgap creepage		
In accordance with the standard	EN 60947-1	EN 60947-1
Overvoltage category	III / II	III / II
Pollution degree	2	2
Rated insulation voltage	250 V	250 V
Rated impulse withstand voltage	4 kV	4 kV
Protection type		
Mounting area (e.g. control cab-		
inet)	IP54	IP54
Housing	IP40	IP40
Terminals	IP20	IP20
Mechanical data	774706	774709
Mounting position	Any	Any
Mechanical life	10,000,000 cycles	10,000,000 cycles
Material		
Bottom	PPO UL 94 V0	PPO UL 94 V0
Front	ABS UL 94 V0	ABS UL 94 V0
Тор	PPO UL 94 V0	PPO UL 94 V0
Connection type	Screw terminal	Screw terminal
Mounting type	Fixed	Fixed
Conductor cross section with screw terminals		
1 core flexible	0,2 - 4 mm <sup>2</sup> , 24 - 10 AWG	0,2 - 4 mm <sup>2</sup> , 24 - 10 AWG
2 core with the same cross section, flexible with crimp connect-		
ors, no plastic sleeve	0,2 - 2,5 mm <sup>2</sup> , 24 - 14 AWG	0,2 - 2,5 mm², 24 - 14 AWG
2 core with the same cross sec- tion, flexible without crimp con- nectors or with TWIN crimp con-		
nectors	0,2 - 2,5 mm², 24 - 14 AWG	0,2 - 2,5 mm², 24 - 14 AWG
Torque setting with screw terminals	0,6 Nm	0,6 Nm
Dimensions		
Height	87 mm	87 mm
Width	90 mm	90 mm
Depth	121 mm	121 mm
Weight	720 g	540 g

Where standards are undated, the 2014-07 latest editions shall apply.

### Safety characteristic data



### **NOTICE**

You must comply with the safety-related characteristic data in order to achieve the required safety level for your plant/machine.

Operating mode	EN ISO 13849-1: 2008	EN ISO 13849-1: 2008	EN 62061 SIL CL	EN 62061 PFH <sub>D</sub> [1/h]		IEC 61511 PFD	EN ISO 13849-1: 2008
	PL	Category					T <sub>м</sub> [year]
_	PL e	Cat. 4	SIL CL 3	2,31E-09	SIL 3	2,03E-06	20

All the units used within a safety function must be considered when calculating the safety characteristic data.



### **INFORMATION**

A safety function's SIL/PL values are **not** identical to the SIL/PL values of the units that are used and may be different. We recommend that you use the PAScal software tool to calculate the safety function's SIL/PL values.

### Supplementary data




#### **CAUTION!**

It is essential to consider the relay's service life graphs. The relay outputs' safety-related characteristic data is only valid if the values in the service life graphs are met.

The PFH value depends on the switching frequency and the load on the relay output. If the service life graphs are not accessible, the stated PFH value can be used irrespective of the switching frequency and the load, as the PFH value already considers the relay's B10d value as well as the failure rates of the other components.

### Service life graph

The service life graphs indicate the number of cycles from which failures due to wear must be expected. The wear is mainly caused by the electrical load; the mechanical load is negligible.



### **Example**

Inductive load: 0.2 A

Utilisation category: AC15

Contact service life: 4 000 000 cycles

Provided the application to be implemented requires fewer than 4 000 000 cycles, the PFH value (see Technical details) can be used in the calculation.

To increase the service life, sufficient spark suppression must be provided on all output contacts. With capacitive loads, any power surges that occur must be noted. With DC contactors, use flywheel diodes for spark suppression.

### Order reference

Product type	Features	Connection type	Order no.
PNOZ X10	24 VAC	Screw terminals	774 700
PNOZ X10	42 VAC	Screw terminals	774 701
PNOZ X10	110 - 120 VAC	Screw terminals	774 703
PNOZ X10	230 - 240 VAC	Screw terminals	774 706
PNOZ X10	24 VDC	Screw terminals	774 709

### EC declaration of conformity

This product/these products meet the requirements of the directive 2006/42/EC for machinery of the European Parliament and of the Council. The complete EC Declaration of Conformity is available on the Internet at www.pilz.com/support/downloads. Representative: Norbert Fröhlich, Pilz GmbH & Co. KG, Felix-Wankel-Str. 2, 73760 Ostfildern, Germany

SafetyEYE®, SafetyNET p® THE SPIRIT OF SAFETY® are registered and protected trademarks of PIIZ GmbH & Co. KG in some countries. We would point out that product features mit from the details stated in this document, depending on the status at the time of publication and the scope of the equipment. We accept no responsibility for the validity, accuracy and entirety of the text and graphics presented in this information. Please contact our Technical Support if you have any questions.

InduraNET p°, PAS4000°, PAScal®, PASconfig«, PIIz«, PIIz», PIID®, PMCprimo®, PMCprotego®, PMCtendo®, PMD®, PMI®, PNOZ®, Primo®, PSEN®, PSS®, PVIS®, SafetyBUS

# Support

Technical support is available from Pilz round the clock.

Americas
Brazil
+55 11 97569-2804
Canada
+1 888-315-PILZ (315-7459)
Mexico
+52 55 5572 1300
USA (toll-free)
+1 877-PILZUSA (745-9872)

### Asia

China +86 21 60880878-216 Japan +81 45 471-2281 South Korea +82 31 450 0680

### Australia

+61 3 95446300

Europe Austria +43 1 7986263-0 Belgium, Luxembourg +32 9 3217575 France +33 3 88104000 Germany +49 711 3409-444 Ireland +353 21 4804983 Italy

+39 0362 1826711

Scandinavia +45 74436332 Spain +34 938497433 Switzerland +41 62 88979-30 The Netherlands +31 347 320477 Turkey +90 216 5775552 **United Kingdom** +44 1536 462203


### You can reach our international hotline on:

+49 711 3409-444 support@pilz.com

Pilz develops environmentally-friendly products using ecological materials and energy-saving technologies. Offices and production facilities are ecologically designed, environmentally-aware and energy-saving. So Pilz offers sustainability, plus the security of using energy-efficient products and environmentally-friendly solutions.











Pilz GmbH & Co. KG Felix-Wankel-Straße 2 73760 Ostfildern, Germany Tel.: +49 711 3409-0 Fax: +49 711 3409-133 info@pilz.com

www.pilz.com

