| data cations 25 400 mm oge 40 400 mm 0 25 mm t plate 20 mm x 20 mm quency approx. 300 kHz s 5 |
|---|
| 25 400 mm nge 40 400 mm 0 25 mm t plate 20 mm x 20 mm quency approx. 300 kHz |
| nge 40 400 mm 0 25 mm t plate 20 mm x 20 mm quency approx. 300 kHz |
| 0 25 mm t plate 20 mm x 20 mm quency approx. 300 kHz |
| t plate 20 mm x 20 mm quency approx. 300 kHz |
| quency approx. 300 kHz |
| |
| ore availability $t_v \leq 150 \text{ ms}$ |
| |
| ble length max. 300 m |
| ating means switching state and flashing: Teach-In |
| fications |
| nal voltage U _e 24 V DC |
| age U _B 20 30 V DC , ripple 10 % _{SS} ; 12 20 V DC reduced |
| sensitivity by 90 % |
| $r \text{ current I}_0 \leq 20 \text{ mA}$ |
| 4 |
| 1 program input low level : 0 0.7 V (Teach-IN active) |
| high level : U _B or open input (Teach-IN inactive) |
| $16 \mathrm{k\Omega}$ |
| ≥3 s |
| |
| 1 switch output PNP, NO |
| nal current I _e 200 mA , short-circuit/overload protected |
| $I_d \leq 2 V$ y $t_{on} \leq 75 \text{ ms}$ |
| yt _{on} ≤ 75 ms cy ±1 mm |
| Jency f 5 Hz |
| sis H typ. 4 mm |
| nt I _r \leq 0.01 mA |
| nfluence + 0.17 %/K |
| |
| erature -25 70 °C (-13 158 °F) rature -40 85 °C (-40 185 °F) |
| ce 30 g , 11 ms period |
| ance 10 55 Hz , Amplitude ± 1 mm |
| cifications |
| M8 x 1 connector , 4-pin |
| ree IP67 |
| Polycarbonate |
| epoxy resin/hollow glass sphere mixture; polyurethane foan |
| ition any position |
| 10 g |
| ue, fastening screws max. 0.2 Nm |
| h standards and |
| ormity |
| EN 60947-5-2:2007 |
| IEC 60947-5-2:2007 |
| |
| certificates |
| |
| cULus Listed, General Purpose |
| cCSAus Listed, General Purpose |
| |

Release date: 2012-04-11 15:29 Date of issue: 2012-04-11 233240_eng.xml


Subject to reasonable modifications due to technical advances.

Copyright Pepperl+Fuchs, Printed in Germany


1

UB400-F77-E2-V31

Dimensions



Electrical Connection



Pinout

2



Wire colors in accordance with EN 60947-5-2

| 1 | BN | (brown) |
|---|----|---------|
| 2 | WH | (white) |
| 3 | BU | (blue) |
| 4 | BK | (black) |

Accessories

UB-PROG4-V31 Programming unit

OMH-ML7-01 Mounting bracket

V31-GM-2M-PVC M8, 4-pin socket, PVC cable

V31-WM-2M-PVC

M8, 4-pin socket, PVC cable

Description of Sensor Function


The ultrasonic sensor transmits ultrasonic packets in quick succession and responds to their reflection off the detected object. The sensor has a switch output. The switching point is programmable (Teach-In). Objects beyond the taught-in switching point are not detected (background suppression).

Teach-In of Switching Point SP

To teach in a switching point, proceed as follows:

- 1. Connect the sensor and turn on the operating voltage.
- 2. Place the object to be detected at the required distance.
- 3. Connect the teach-in input (ET) to -U_B. This can be done usingthepushbutton or the controller.
- The LED will start flashing after 3 seconds to indicate that the sensor is ready to start the teach-in process (*).
- 4. Disconnect the teach-in input (ET) with $-U_B$. The switching point SP has now been taught in ^(*).
- (*) If no object is detected within the sensing range of the sensor, the sensor will start flashing at a faster rate. The switching point remains unchanged.

Switching characteristics and display LED



= Object position

Mounting instruction

If the sensor is operated at temperatures below 0 °C, use the supplied distance plate. Only use the two rearmost mounting holes (located opposite to the transducer) for mounting the sensor.

Safety Note

The use of this device in applications, where the safety of persons depends from the devices function, is not allowed!



Copyright Pepperl+Fuchs, Printed in Germany